SPORTENZIA

FITTING GUIDE

TPU PROTECTIVE CASE FOR COROS PACE 4

Black TPU bumper case that covers the sides and four corners of the COROS PACE 4, with a raised lip in front of the screen. Crown, button, sensor and charging stay accessible. Fitting, removal and care on one page.

REF. COQUPACE4 · COROS PACE 4 · SOFT TPU, BLACK



Before you start

The case is cut for the COROS PACE 4 only: one opening for the crown, one for the lower button, an opening at the back for the sensor, a notch for the charger. It clips on without tools.

Fitting the case

1. **Clean the watch body** with a soft, dry cloth: a grain of sand trapped under the TPU scratches over time. If the strap gets in the way, detach it while you fit the case.
2. **Line up the case** crown opening on the crown side, lugs aligned with those of the watch, back opening towards the wrist.
3. **Hook the crown side first** crown in its opening, then gently stretch the TPU to bring the other side over. Pull on the solid edge, never on an opening.
4. **Check all the way round** the edge sits flat without ripples, the crown turns and presses freely, the button responds, the raised lip stands evenly all around the screen.
5. **Check the back** the heart-rate sensor is centred in the opening, the charging connector in the notch. Plug in the charger: the case stays on.

REMOVING THE CASE

Lift the TPU at one lug with a fingernail, then roll the case off towards the other side. It can be refitted as many times as needed.

Day to day

- Rinse the watch in fresh water after the sea or the pool, case on, then dry it: salt and chlorine otherwise stay under the TPU.
- Take the case off now and then to clean the body underneath: dust that creeps in marks the finish.
- Face down on a table, the watch rests on the raised lip, not on the screen: check this lip after a knock.

Specifications

Compatibility	**COROS PACE 4**	Material	**Soft TPU**
Colour	**Black**	Height	**50.5 mm**
Width	**45.5 mm**	Thickness	**13.4 mm**
Contents	**1 case**		

GOOD TO KNOW

- The raised lip keeps the screen off the table when the watch lies face down; it does not replace a screen film or glass.
- Ripples, or the crown rubs? The case is off-centre, or the watch is not a PACE 4. Take it off and start again from the crown side.
- Wash the case in warm soapy water and dry it before refitting. No alcohol or solvent: they dull and harden TPU.
- TPU that turns white or has stretched no longer holds: replace it.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and compatibility.

© 2026 Sportenzia. All rights reserved.