SPORTENZIA

USER GUIDE

DIGITAL HANGING SCALE 60 KG

Hook scale for weighing a bike, a suitcase, a parcel or a catch up to 60 kg, in 10 g steps. Backlit display, battery recharged over USB. Setting up, controls, charging and troubleshooting.

REF. BALNUM1BLCK · 60 KG, 10 G RESOLUTION · 200 MAH BATTERY, USB CHARGING



01 · GETTING STARTED

CONTENTS, FIRST WEIGHING, SAFETY

In the box

- The scale: handle, LCD display, three buttons (TARE, power, UNIT) and a stainless steel hook that folds into the back.
- A USB cable for charging.
- The maker's manual.

First weighing

1. **Charge the scale** with the supplied USB cable, plugged into the port on the side of the unit, from a charger, a computer or a power bank.
2. **Unfold the hook** stowed in the back of the scale, until it hangs freely in line with the handle.
3. **Switch on** with the power button, holding the scale by its handle with nothing attached. Wait for the display to show zero.
4. **Pick the unit** with UNIT: kg, lb, jin or oz. The current unit shows next to the reading.
5. **Hook the load** by a handle, a strap or a sturdy loop, then lift gently and straight until the load is clear of the ground.
6. **Read the weight** once the value on the display is steady. Set the load down before unhooking it.

GOOD TO KNOW

- For a bike, pass a strap under the frame or hook the saddle rails rather than a cable or a spoke.
- For luggage, use the suitcase or bag handle: thin loops are not made to carry the full weight.
- Weigh out of the wind and wait until the load stops moving: the 10 g resolution assumes a still load.

Specifications

Capacity	**60 kg**	Resolution	**10 g**
Units	**kg, lb, jin, oz**	Temperature	**°C**
Display	**Backlit LCD**	Battery	**200 mAh, USB charging**
Hook	**Stainless steel, folding**	Material	**ABS**
Dimensions	**21.6 × 8.8 × 2.8 cm**		

SAFETY

- Never exceed 60 kg: beyond that the mechanism is damaged and the load can drop.
- Never hang from the scale yourself and never hang a person from it.
- Hold the handle with both hands for a heavy load, feet clear of the load, and lift with your legs, not your back.
- Check that the loop or strap carrying the load is sound: it is what gives way first.

02 · DAY TO DAY

CONTROLS, CHARGING, TROUBLESHOOTING

The controls

Power	Switches the scale on and off.
UNIT	Cycles through the units: kg, lb, jin, oz.
TARE	Zeroes the display with a container hooked on: you then weigh only what you put in it.
Display	Weight, unit, battery level and temperature in °C. The backlight can be turned off to save battery (key combination: maker's manual).

If something goes wrong

SYMPTOM	LIKELY CAUSE	FIX
Display stays blank	Battery empty	Charge over USB, then try again
Reading keeps changing	Swinging load, wind, low battery	Wait for stillness, find shelter, recharge
No zero shown at switch-on	Something was hanging from the hook	Switch off, unhook everything, switch on again or press TARE
Weight looks wrong	Wrong unit, load partly resting on the ground	Check the unit, lift fully
Display shows an error message	Load above 60 kg	Set the load down at once



The stainless hook folds into the back of the scale for transport.

Charging and care

- Recharge as soon as the battery indicator is low: an underpowered scale gives unsteady readings.
- Charge somewhere dry, at room temperature. Stored for several months, recharge it before use.
- Wipe the housing with a slightly damp cloth, never under running water: the electronics are not waterproof. Rinse and dry the stainless hook after a sea fishing trip.
- Fold the hook away before storing the scale and keep the display away from knocks.

TIP

- To get the net weight of a catch or a load, hang the empty bucket or bag first, press TARE, then fill it.
- In low light the backlight keeps the display readable; turn it off in daylight to spare the battery.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about use and charging.