SPORTENZIA

QUICK GUIDE

# USB CHARGING CABLE FOR COROS WATCHES

1 m USB cable with a Coros connector to charge Pace, Apex and Vertix watches from a computer, a wall charger or a car USB socket. Plugging in, compatible models, safety and troubleshooting on one page.

**REF. CABCOROS1M** · COROS PACE 2 / 3, APEX, APEX PRO, VERTIX, VERTIX 2 · USB, 1 M, TPE AND TPU



## Before plugging in

The connector plugs into the charging port on the back of the watch and stays put without disconnecting at the slightest movement. It only goes in one way: the small triangle moulded on the connector is the guide. Leave the watch lying flat while it charges.

## Charging

1. **Plug the USB end** into a computer, a wall charger or a car USB socket: a standard 5 V USB source is all it needs.
2. **Wipe the contacts** on the back of the watch and on the connector with a dry cloth: no sweat, no sand, no moisture.
3. **Push the connector in** with the triangle lined up with the watch port. If it resists, turn it over rather than forcing it: the pins are thin.
4. **Check the screen** of the watch: it must show that it is charging. Stay nearby during the first charge.
5. **Unplug once charging is complete** by pulling on the connector, never on the cable.

## Compatible watches

| SERIES | MODELS |
|---|---|
| Pace | Pace 2, Pace 3 |
| Apex | Apex, Apex Pro, Apex 42 / 46 mm |
| Vertix | Vertix, Vertix 2 |

## Day to day

- Store the cable coiled, without bending the connector or leaving it loose at the bottom of a bag with keys.
- The TPE and TPU jacket wipes clean with a slightly damp cloth; let it dry before plugging in.
- The short-circuit and overvoltage protection looks after the watch, it does not replace a proper USB source.

## Specifications

| | | | |
|---|---|---|---|
| Length | **1 m** | Plug | **USB** |
| Connector | **Coros, pin type** | Materials | **TPE + TPU** |
| Protection | **Short circuit, overvoltage** | Contents | **1 cable (no adapter)** |

**ELECTRICAL SAFETY**

- Standard 5 V USB source only: no high-voltage fast charger.
- Never charge a wet watch: dry it first, port included.
- Split jacket, exposed wires, connector getting hot: discard the cable.

**IF IT DOES NOT CHARGE**

- Dirty or damp contacts: clean them with a dry cloth.
- Connector not fully in or the wrong way round: take it out and try the other way.
- Weak source (USB port on a keyboard or monitor): try a wall charger.
- Watch not in the list: the port is not the same.

## Need help?

**sportenzia.com/pages/contact**

Our team answers your questions about compatibility and use.

© 2026 Sportenzia. All rights reserved.