SPORTENZIA

QUICK GUIDE

USB CHARGING CABLE FOR GARMIN WATCHES

100 cm USB cable with a Garmin connector to charge the Fenix 7, 7S, 7X, the Forerunner 255 and 955 and the other Garmin watches that use the same charging connector. Plugging in, safety and troubleshooting on one page.

REF. CABLECHARGE1 · FENIX 7, 7S, 7X; FORERUNNER 255, 955 · USB, 100 CM



Before plugging in

The connector plugs into the charging port on the back of the watch and only goes in one way: the triangle moulded on the connector is the guide. The USB plug goes into a charger, a computer or a power bank; no mains adapter is supplied.

Charging

1. **Plug the USB end** into a charger, a computer or a power bank: a standard 5 V USB source is all it needs.
2. **Wipe the contacts** on the back of the watch and on the connector with a dry cloth: no sweat, no sand, no moisture.
3. **Push the connector in** with the triangle lined up with the watch port. If it resists, turn it over rather than forcing it: the pins are thin.
4. **Check the screen** of the watch: it must show that it is charging. Stay nearby during the first charge.
5. **Unplug once charging is complete** by pulling on the connector, never on the cable.



The connector plugs into the charging port on the back of the watch.

Compatible watches

- Garmin Fenix 7, 7S and 7X.
- Garmin Forerunner 255 and 955.
- Other Garmin watches fitted with the same charging connector: compare the shape of the port with the connector before plugging in.

Specifications

Length	**100 cm**	Plug	**USB**
Connector	**Garmin, pin type**	Contents	**1 cable, no mains adapter**

ELECTRICAL SAFETY

- Standard 5 V USB source only: no high-voltage fast charger.
- Never charge a wet watch: dry it first, port included.
- Split jacket, exposed wires, connector getting hot: discard the cable.

IF IT DOES NOT CHARGE

- Dirty or damp contacts: clean them with a dry cloth.
- Connector not fully in or the wrong way round: take it out and try the other way.
- Weak source (USB port on a keyboard or monitor): try a wall charger.
- Port of a different shape: the watch does not use this connector.

DAY TO DAY

Store the cable coiled without bending the connector, and keep it away from sand and keys at the bottom of a bag: the charging pins are the fragile part.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about compatibility and use.

© 2026 Sportenzia. All rights reserved.