SPORTENZIA

FITTING GUIDE

SILICONE PROTECTIVE CASE FOR GARMIN FORERUNNER 165

Soft black silicone case that dresses the body of the Garmin Forerunner 165. Buttons press through caps, the sensor and charging use the opening at the back. Fitting, removal and care on one page.

REF. COQG165 · GARMIN FORERUNNER 165 · SOFT SILICONE, BLACK



Before you start

The case is moulded for the Garmin Forerunner 165 only. The buttons do not go through holes: each is capped with silicone, three on one side, two on the other. Fit the case to a clean, dry watch, no tool needed.

Fitting the case

1. **Clean the watch body** with a soft, dry cloth, right under the lugs: a grain of sand trapped under the silicone scratches over time. If the strap gets in the way, detach it while you fit the case.
2. **Line up the case** caps facing the buttons, three on one side, two on the other. The opening at the back faces the wrist.
3. **Hook one side** over the body, then gently stretch the silicone to bring the other side over. Pull on the solid edge, never on a lug or a cap.
4. **Check all the way round** the edge sits flat without ripples, each cap is centred on its button. Press each button through the silicone: it must respond.
5. **Check the back** heart-rate sensor and charging connector show through the opening. Plug in the charger: it clips on without removing the case.

REMOVING THE CASE

Lift the silicone at one lug with a fingernail, then roll the case off towards the other side. It can be refitted as many times as needed.



At the back: one opening for the heart-rate sensor and the charging connector.

Specifications

Compatibility	**Garmin Forerunner 165**	Material	**Soft silicone**
Colour	**Black**	Making	**Compression moulded**
Protection	**Knocks, scratches, wear**	Buttons	**Soft caps**
Contents	**1 case**		

GOOD TO KNOW

- The case protects the edges and sides of the body, not the face of the screen: add a screen film or glass for that.
- A button hard to press? Its cap is off-centre: take the case off and recentre it. If it will not go on, the watch is not a Forerunner 165.
- Silicone attracts dust: wash the case in warm soapy water and dry it before refitting. No alcohol or solvent.
- Silicone that has stretched, split or turned sticky no longer holds: replace it.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and compatibility.

© 2026 Sportenzia. All rights reserved.