SPORTENZIA

FITTING GUIDE

SOFT SILICONE CASE FOR GARMIN VIVOACTIVE 6 / ACTIVE 6

Black silicone bumper case that surrounds the body of the Garmin Vivoactive 6 (Active 6). Buttons, screen, sensor and charging stay accessible, the back is open. Fitting, removal and care on one page.



REF. COQGVIVO6 · GARMIN VIVOACTIVE 6 / ACTIVE 6 · SOFT SILICONE, BLACK

Before you start

The case is moulded for the Garmin Vivoactive 6, also called Active 6, only: two openings on one side for the buttons, a fully open back. Fit it to a clean, dry watch, no tool needed.

Fitting the case

1. **Clean the watch body** with a soft, dry cloth, right under the lugs: a grain of sand trapped under the silicone scratches over time. If the strap gets in the way, detach it while you fit the case.
2. **Line up the case** button openings on the button side, lugs aligned with those of the watch, open side towards the wrist.
3. **Hook one side** over the body, then gently stretch the silicone to bring the other side over. Pull on the solid edge, never on a lug or an opening.
4. **Check all the way round** the edge sits flat without ripples, both buttons stand proud of their opening and press freely, the screen is clear.
5. **Check the back** heart-rate sensor and charging connector are clear, the case is open there. Plug in the charger: it clips on without removing the case.

REMOVING THE CASE

Lift the silicone at one lug with a fingernail, then roll the case off towards the other side. It can be refitted as many times as needed.



Open back: heart-rate sensor and charging connector fully clear.

Specifications

Compatibility	**Garmin Vivoactive 6 / Active 6**
Material	**Soft silicone**
Colour	**Black**
Protection	**Knocks, scratches, bumper**
Buttons	**Two openings**
Back	**Open**
Contents	**1 case**

GOOD TO KNOW

- The case protects the edges and sides of the body, not the face of the screen: add a screen film or glass for that.
- Ripples, or a button that stays pressed? The case is off-centre, or the watch is not a Vivoactive 6. Take it off and start again from the other side.
- Silicone attracts dust: wash the case in warm soapy water and dry it before refitting. No alcohol or solvent.
- Silicone that has stretched, split or turned sticky no longer holds: replace it.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and compatibility.

© 2026 Sportenzia. All rights reserved.