SPORTENZIA

FITTING GUIDE

SOFT TPU PROTECTIVE CASE FOR COROS PACE 3

Soft black TPU case that wraps the body of the COROS PACE 3. The crown goes through its opening, the button stays usable, the back is open for the sensor and charging. Fitting, removal and care on one page.

REF. COQPACE3 · COROS PACE 3 · SOFT TPU, BLACK



Before you start

The case is cut for the COROS PACE 3 only: a large opening for the crown, the lower button just below it, an open back. It clips on without tools.

Fitting the case

1. **Clean the watch body** with a soft, dry cloth: a grain of sand trapped under the TPU scratches over time. If the strap gets in the way, detach it while you fit the case.
2. **Line up the case** crown opening on the crown side, lugs aligned with those of the watch, open side towards the wrist.
3. **Hook the crown side first** crown in its opening, then gently stretch the TPU to bring the other side over. Pull on the solid edge, never on the opening.
4. **Check all the way round** the edge sits flat without ripples, the crown turns and presses freely, the button responds, the screen is clear.
5. **Check the back** the heart-rate sensor is clear and the charging connector sits in the notch. Plug in the charger: the case stays on.

REMOVING THE CASE

Lift the TPU at one lug with a fingernail, then roll the case off towards the other side. It can be refitted as many times as needed.

Day to day

- Rinse the watch in fresh water after the sea or the pool, case on, then dry it: salt and chlorine otherwise stay under the TPU.
- Take the case off now and then to clean the body underneath: dust that creeps in marks the finish.
- The charger plugs in with the case on; if it catches, check that the notch at the back lines up with the connector.

Specifications

Compatibility	**COROS PACE 3**	Material	**Soft TPU**
Colour	**Black**	Type	**Full-wrap case**
Protection	**Scratches, rubbing, light knocks**	Fitting	**Clip-on, no tool**
Contents	**1 case**		

GOOD TO KNOW

- The case protects the edges and sides of the body, not the face of the screen: add a screen film or glass for that.
- Ripples, or the crown rubs? The case is off-centre, or the watch is not a PACE 3. Take it off and start again from the crown side.
- Wash the case in warm soapy water and dry it before refitting. No alcohol or solvent: they dull and harden TPU.
- TPU that turns white or has stretched no longer holds: replace it.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and compatibility.

© 2026 Sportenzia. All rights reserved.