SPORTENZIA

FITTING GUIDE

SOFT TPU CASE FOR GARMIN FORERUNNER 70, 170 AND 170 MUSIC

Black TPU bumper case with cut-outs for the Garmin Forerunner 70, 170 and 170 Music. Buttons go through openings, the back stays open for the sensor and charging. Fitting, removal and care on one page.

REF. COQU17070 · FORERUNNER 70, 170, 170 MUSIC · SOFT TPU, BLACK



Before you start

The case is cut for the Garmin Forerunner 70, 170 and 170 Music only (same body). Each opening matches a button, three on one side, two on the other. No tool needed.

Fitting the case

1. **Clean the watch body** with a soft, dry cloth: a grain of sand trapped under the TPU scratches over time. If the strap gets in the way, detach it while you fit the case.
2. **Line up the case** openings facing the buttons, three on one side, two on the other. The open back faces the wrist.
3. **Hook one side** over the body, then gently stretch the TPU to bring the other side over. Pull on the solid edge, never on an opening: that is where TPU tears.
4. **Check all the way round** the edge sits flat without ripples or bulges, each button stands proud of its opening and presses freely.
5. **Check the back** heart-rate sensor and charging contacts are clear, the case is open there. Plug in the charger: it clips on without removing the case.

REMOVING THE CASE

Lift the TPU at one lug with a fingernail, then roll the case off towards the other side. It can be refitted as many times as needed.

Day to day

- Rinse the watch in fresh water after the sea or the pool, case on, then dry it: salt and chlorine otherwise stay under the TPU.
- Take the case off now and then to clean the body underneath: dust that creeps in marks the finish.
- After a knock, check that the case still sits flat: a lifted edge lets sand in.

Specifications

Compatibility	**Garmin Forerunner 70, 170, 170 Music**	Material	**Soft TPU**
Colour	**Black**	Type	**Open bumper**
Protection	**Scratches, everyday knocks**	Charging	**With the case on**
Contents	**1 case**		

GOOD TO KNOW

- The case protects the edges and sides of the body, not the face of the screen: add a screen film or glass for that.
- Ripples, or a button that stays pressed? The case is off-centre, or the watch is not a Forerunner 70 or 170. Take it off and start again from the other side.
- Wash the case in warm soapy water and dry it before refitting. No alcohol or solvent: they dull and harden TPU.
- TPU that turns white or has stretched no longer holds: replace it.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and compatibility.