SPORTENZIA

USER GUIDE

CYCLAMI M6W OUT-FRONT MOUNT

Out-front mount that places your GPS bike computer ahead of the handlebar, in line with the bike, with three interchangeable Garmin, Wahoo and Bryton bases. Fitting on a round handlebar, changing bases, care and troubleshooting.

REF. CYCLAMIM6W · BAR 25.4 / 31.8 MM · GARMIN, WAHOO, BRYTON



01 · GETTING STARTED

CONTENTS, FITTING, CHECKS

In the box

- The CYCLAMI M6W out-front mount: a handlebar clamp, an arm and a head that takes the computer base.
- Three mounting bases: Garmin, Wahoo (marked W) and Bryton (marked B).
- The parts needed to fit the mount.

What the mount does

The arm brings the head ahead of the handlebar: the computer sits in line with the bike, in your field of view, without looking away. The base changes with the computer's brand, without removing the mount.

Before you start

Check your handlebar diameter where the mount will sit: **25.4 or 31.8 mm**, on a round section. Have a hex key that fits the mount's screws.

Fitting

1. **Pick the configuration** that matches your handlebar diameter from the supplied fitting parts.
2. **Place the clamp** loosened, on the round section of the bar, next to the stem.
3. **Point the arm** forwards: the head should sit ahead of the stem, in line with the bike, roughly level.
4. **Tighten the clamp** gradually and alternately, until the mount no longer turns by hand. Do not force it, especially on a carbon bar.
5. **Fit the base** for your computer's brand (see page 02), then clip the computer on and twist it until it locks.
6. **Check while stationary** that the computer does not move and the screen reads without dropping your head. If not, loosen the clamp, rotate it on the bar, retighten.

Specifications

Model	**M6W**	Position	**Out-front of the bar**
Handlebar	**Round**	Diameters (mm)	**25.4 / 31.8**
Computers	**Garmin, Wahoo, Bryton**	Bases	**3 interchangeable**
Material	**PVC**	Dimensions (mm)	**137 × 54 × 62**

ON THE ROAD

- Before every ride, check that the computer is locked and the mount does not turn on the bar.
- The mount must not interfere with cables, brakes or steering.
- Read the screen at a glance; operate the computer when stopped.
- After a crash or knock, inspect the mount: if cracked or bent, stop using it.

GETTING IT RIGHT

- Tilt the screen slightly towards you by rotating the clamp: a flat screen reflects more of the sky.
- Leave enough room around the head to clip and twist the computer without touching the stem.
- If you change handlebars, measure the diameter again before refitting the mount.

02 · DAY TO DAY

BASES, CARE, TROUBLESHOOTING

Which base for which computer

Garmin	Computers with the Garmin quarter-turn mount, or a compatible Garmin-type interface.
Wahoo (W)	Compatible Wahoo computers.
Bryton (B)	Compatible Bryton computers.

Changing the base

1. **Remove the computer** by twisting it opposite to the locking direction.
2. **Unscrew the base** (two screws) with a hex key. Keep the screws.
3. **Fit the new base** flat on the head, holes aligned, turned so the locked computer sits straight in front of you.
4. **Refit the two screws** and tighten them alternately, firmly, without forcing.
5. **Test the hold** by clipping and locking the computer, then pulling on it: it must hold with no play.

If something goes wrong

SYMPTOM	LIKELY CAUSE	FIX
Mount turns on the bar	Not tight enough, or configuration wrong for the diameter	Check the diameter, retighten alternately
Computer will not lock	Base for another brand	Fit the base matching the computer
Computer crooked when locked	Base turned wrongly	Unscrew, rotate the base, screw back
Screen hard to read	Mount angle	Loosen the clamp, rotate it, retighten
Computer has play	Base screws loose	Tighten both screws



Clamp on the bar next to the stem, computer in line, ahead of the bar.

Care

- Clean with warm soapy water and a soft cloth, then dry.
- Avoid solvents, harsh degreasers and pressure washing on the mount.
- Now and then, check the tightness of the clamp and the base screws.
- Keep unused bases with their screws, ready for another computer.

GOOD TO KNOW

- Fit on a round section of the bar only, not on an oval, flat or integrated section.
- The mount is PVC: an overtightened screw can mark or split the part.
- Choose the base by your computer's mounting system: if in doubt, compare it with the computer's original mount.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and compatibility.