SPORTENZIA

USER GUIDE

CYCLAMI S2 XL OUT-FRONT MOUNT

Handlebar mount with an extended arm that places a Garmin Edge computer ahead of the stem, with a GoPro-type mount underneath for a light or a camera. Fitting, compatibility, care and troubleshooting.

REF. CYCLAMIS2BLUE · GARMIN EDGE, 141 MM XL ARM · GOPRO-TYPE LOWER MOUNT



01 · GETTING STARTED

CONTENTS, FITTING, FIRST RIDE

In the box

- The S2 mount: hinged handlebar clamp, extended arm, head fitted with the Garmin Edge interface.
- The GoPro-type lower adapter, which screws under the head.
- The mounting hardware: clamp screw and adapter screws. Have a suitable hex key ready.

Fitting

1. **Choose the spot** on a round, smooth section of the handlebar, next to the stem, clear of cables and housings.
2. **Open the clamp** by removing its screw, then swing it around the bar on its hinge, black ring in place inside.
3. **Position the arm** pointing forwards, head centred ahead of the stem, top face level. The computer must not touch the stem.
4. **Tighten the clamp screw** gradually, just enough that the mount no longer turns by hand. On a carbon bar, follow its maker's instructions.
5. **Screw on the lower adapter** under the head with its two screws, if you are fitting a light or a camera.
6. **Lock the computer** set crosswise on the interface, then turned a quarter turn to the stop. Pull on it: it must hold.
7. **Attach the accessory** to the adapter with its own clamping screw, facing the road.

Specifications

Model	**CYCLAMI S2**	Colour	**Blue**
Length	**≈ 141 mm**	Weight	**≈ 49 g**
Material	**CNC-machined aluminium**	Top interface	**Garmin Edge**
Lower interface	**GoPro type**	Accessories	**Light, action camera**

ON THE ROAD

- Before every ride, check that the computer and accessory are locked and all hardware is tight.
- A camera or light adds weight up front: check the clamp after the first few kilometres.
- Aim the light at the road without dazzling oncoming traffic.
- Adjust computer and camera while stationary, never on the move.

02 · DAY TO DAY

COMPATIBILITY, CARE, TROUBLESHOOTING

Compatibility

Garmin Edge 530, 540, 830, 840	Compatible.
Garmin Edge 1030, 1040, 1050	Compatible: the XL arm gives them room ahead of the stem.
Underneath	Light or camera with a GoPro-type mount: GoPro, Insta360 or another compatible camera.
Other computers	Not listed: contact us before fitting.

Care

- Clean the mount with a damp cloth, then dry it, computer and accessory removed.
- Check the clamp, interface and adapter screws for tightness regularly.
- When transporting the bike, remove computer and camera: a knock on the head loads the clamp.

If something goes wrong

SYMPTOM	LIKELY CAUSE	FIX
Mount turns on the bar	Clamp screw too loose, ring misplaced	Reseat the ring, tighten gradually
Computer will not lock	Set badly or not turned far enough	Set it crosswise, turn to the stop
Computer has play	Interface screws loose	Tighten both interface screws
Accessory tips forward	Adapter or accessory screw loose	Tighten, check the angle
Clamp will not close	Unsuitable bar diameter	Do not force it, contact us



Garmin interface on top, GoPro-type adapter and its two screws below, clamp screw on the right.

GOOD TO KNOW

- The clamp is round: fit it on a round section of the bar, not on a flattened area.
- Overtightening will not fix a mount that turns: check the ring and position first.
- The computer sits on top, the accessory below: leave room for the light or camera.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and compatibility.