SPORTENZIA

QUICK GUIDE

SEMI-RIGID CASE FOR SPORTS GLASSES

Zipped case with a rigid black PU face and a soft mesh face, plus a clip to hang it. It keeps sports glasses safe from scratches, knocks and crushing inside a bag. Use and care on one page.

REF. HOCLUNBLCK1 · CYCLING, SKI, SPORTS GLASSES · 22 × 12.5 CM, 60 G



Before use

The case measures about 22 × 12.5 cm: it takes wraparound sports glasses with wide lenses, arms folded. The domed rigid face forms the protective shell; the soft mesh face follows the shape of the glasses and keeps the case slim. The zip runs around the case, with a swivel clip fixed near the slider.

Storing and carrying

1. **Open the case** by pulling the slider to the end of the zip, without forcing.
2. **Fold the arms** and lay the glasses lenses against the rigid face, arms on the mesh side. A frame that is too wide or too tall strains the zip: do not force it in.
3. **Close** guiding the slider with one hand while the other holds the glasses in place, so the zip never rubs on the lenses.
4. **Clip the case** to a strap or ring on a backpack, or slip it into a sports bag, rigid face outwards.
5. **On the bike** keep the case in a bag or backpack, never hanging from the handlebar or frame: it could catch in the wheel.

Specifications

Dimensions	22 × 12.5 cm	Weight	About 60 g
Outer	Black PU	Design	Rigid + soft
Sports	Bike, ski, outdoor	Contents	1 case



Glasses stored with arms folded, lenses against the rigid face.

GOOD TO KNOW

- Semi-rigid: the case takes the weight of a bag and small knocks, not someone sitting on it.
- Store the glasses clean and dry: trapped sand or sweat scratches the lenses and stains the mesh.
- Clean with a damp sponge, air-dry open. No washing machine, no solvent.
- A grain of sand jams the zip: brush the teeth before pulling.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about use and compatibility.

© 2026 Sportenzia. All rights reserved.