SPORTENZIA

FITTING GUIDE

HYDROGEL SCREEN PROTECTORS FOR GARMIN VÍVOACTIVE 6

Two soft, thin, clear hydrogel films that protect the screen of your Garmin vívoactive 6 from scratches, smudges and dust without affecting touch response. Preparation, fitting, first days.

REF. HYDRVIVO6 · GARMIN VÍVOACTIVE 6 · 2 HD HYDROGEL FILMS



Before you start

- Work in a room with little dust, hands clean and dry, watch lying flat.
- Clean the screen, then wipe it with a soft lint-free cloth: a speck of dust or a smudge left under the film makes a bubble that will not go away.
- The second film is a spare: keep it in its packaging to replace the first one once it is marked.

Fitting the film

1. **Peel off the liner** that protects the adhesive side of the film, without touching that side with your fingers.
2. **Line up the film** over the screen, centred, with an even gap to the edge all the way round. Lay it down without pressing: it settles by itself.
3. **Smooth from the centre outwards** with a finger or the cloth to push the air out. The film is soft and follows the curve of the screen.
4. **Push out any remaining bubbles** towards the nearest edge. Tiny bubbles under a hydrogel film usually fade on their own within a few hours.
5. **Remove the top layer** if there is one, lifting it by a corner, then wipe once more.
6. **Let it rest** with the watch flat, not worn and kept dry, while the adhesive sets: overnight is a good guide.

Day to day

- Clean the film with a soft, barely damp cloth. No solvents or abrasive products: they dull the anti-smudge surface.
- The film takes the micro-scratches and small abrasions instead of the glass. It does not make the watch unbreakable: a hard knock is still a knock.
- A marked film is replaced: lift it by an edge with a fingernail, clean the screen and fit the second film the same way.

Specifications

Watch	**vívoactive 6**	Contents	**2 films**
Material	**Soft hydrogel**	Finish	**HD anti-smudge**
Format	**Edge to edge**	Touch	**Preserved**

IF SOMETHING GOES WRONG

- A bubble that will not go: there is dust under it. Gently lift the nearest corner, pick the speck off with a piece of sticky tape, lay the film back down.
- An edge lifts: the screen was not clean enough, or the film went on off-centre. Clean and refit, or move on to the second film.
- Touch feels less responsive right after fitting: normal until the air has worked out, sensitivity returns as the film bonds.

DO NOT

- Do not fit the film on a screen that is still damp: let it dry after cleaning.
- Do not reposition a film more than twice: the adhesive loses its grip and picks up dust.
- Do not trim the film: it is cut for the vívoactive 6 and does not suit another model.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and care.

© 2026 Sportenzia. All rights reserved.