SPORTENZIA

FITTING GUIDE

GARMIN FORERUNNER 255 PROTECTION PACK: CASE AND FILMS

A soft TPU case for the body and two HD hydrogel films for the screen of your Garmin Forerunner 255. The film goes on first, the case comes after: preparation, fitting, checks.

REF. PACKPROTECG255BLK · GARMIN FORERUNNER 255 · CASE + 2 FILMS



In the box

- A black soft TPU protective case cut for the Garmin Forerunner 255: buttons, sensor and charging connector stay accessible.
- Two hydrogel films for the screen: one to fit, one spare for the day the first one gets marked.

The film, then the case

1. **Clean the screen** then wipe it with a soft lint-free cloth. Watch flat, hands clean: a speck of dust under the film makes a bubble that will not go away.
2. **Peel off the liner** that protects the adhesive side of the film, without touching that side.
3. **Line up the film** over the screen, centred, with an even gap to the edge. Lay it down without pressing: it settles by itself.
4. **Smooth from the centre outwards** with a finger or the cloth to push the air out, then remove the top layer if there is one. Tiny bubbles usually fade on their own within a few hours.
5. **Clip on the case** openings in line with the buttons. Engage one side of the case body, then stretch the shell slightly to pass the other side. It should wrap the body without creases.
6. **Check** that every button works and that the case does not lift the edge of the film. The watch charges with the case on. Let it rest overnight before wearing the watch.

Day to day

- After sweat or water, take the case off, rinse it in clean water and dry both body and case before refitting.
- Clean the film with a soft, barely damp cloth, no solvents. A scratched film is replaced with the second one, screen cleaned first.

Specifications

Watch	**Forerunner 255**	Contents	**Case + 2 films**
Case	**Soft TPU**	Films	**HD hydrogel**
Colour	**Black**	Charging	**Case on**
Touch	**Preserved**		

IF SOMETHING GOES WRONG

- A bubble that will not go: there is dust under it. Lift the nearest corner, pick the speck off with a piece of sticky tape, lay the film back down.
- The case lifts an edge of the film: the film is off-centre. Take the case off, recentre the film or move on to the second one, then refit the case.
- A button responds poorly: the case is not fully snapped on or has turned. Take it off and refit it square.

DO NOT

- Do not pull the case off by its lugs: ease it off from one side of the body.
- Do not trim the film or the case: they are cut for the Forerunner 255 and do not suit another model.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting.

© 2026 Sportenzia. All rights reserved.