SPORTENZIA

FITTING GUIDE

GARMIN VÍVOACTIVE 5 PROTECTION PACK: CASE AND FILMS

A rigid polycarbonate case for the body and two 9D Full Cover hydrogel films for the screen of your Garmin vívoactive 5. The film goes on first, the case comes after: preparation, fitting, checks.

REF. PACKPROTECVIVO5BLK · GARMIN VÍVOACTIVE 5 · CASE, 2 FILMS, KIT



In the box

- A black rigid polycarbonate protective case cut for the Garmin vívoactive 5: buttons, sensor and charging connector stay accessible.
- Two hydrogel films for the screen: one to fit, one spare for the day the first one gets marked.
- A cleaning kit: a wipe and a cloth.

The film, then the case

1. **Clean the screen** with the wipe from the kit, then dry it with the cloth. Watch flat, hands clean: a speck of dust under the film makes a bubble that will not go away.
2. **Peel off the liner** that protects the adhesive side of the film, without touching that side.
3. **Line up the film** over the screen, centred, with an even gap to the edge. Lay it down without pressing: it settles by itself.
4. **Smooth from the centre outwards** with a finger or the cloth to push the air out, then remove the top layer if there is one. Small bubbles and micro-scratches fade on their own in about 48 h.
5. **Clip on the case** openings in line with the buttons. Offer it up square, engage one side then the other and press around the rim until it snaps on. Polycarbonate is rigid: do not force it at an angle.
6. **Check** that every button works and that the case does not lift the edge of the film. The charging connector must stay clear. Let it rest overnight before wearing the watch.

Day to day

- After sweat or water, take the case off, rinse it in clean water and dry both body and case before refitting.
- Clean the film with a soft, barely damp cloth, no solvents. A scratched film is replaced with the second one, screen cleaned first.

Specifications

Watch	**vívoactive 5**	Contents	**Case, 2 films, kit**
Case	**Rigid polycarbonate**	Films	**9D Full Cover hydrogel**
Colour	**Black**	Charging	**Connector clear**
Touch	**Preserved**		

IF SOMETHING GOES WRONG

- A bubble still there after 48 h: there is dust under it. Lift the nearest corner, pick the speck off with a piece of sticky tape, lay the film back down.
- The case lifts an edge of the film: the film is off-centre. Take the case off, recentre the film or move on to the second one, then refit the case.
- A button responds poorly: the case is not fully snapped on or has turned. Take it off and refit it square.

DO NOT

- Do not pry the case off by an edge with a tool: free it by hand, one side after the other.
- Do not trim the film or the case: they are cut for the vívoactive 5 and do not suit another model.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting.

© 2026 Sportenzia. All rights reserved.