SPORTENZIA

FITTING GUIDE

SELF-ADHESIVE ARROW REST PADS IN SYNTHETIC HAIR

Two self-adhesive pads with a synthetic hair surface, one rectangular and one triangular, that dress the sight window of a recurve or traditional bow: the shaft glides on a soft surface instead of rubbing on the bow. Fitting and care on one page.



REF. PATCHTIR2 · RECURVE AND TRADITIONAL BOWS · RECTANGLE 5 × 1.6 CM, TRIANGLE 2.8 × 2.5 CM

Before you start

The two pads cover the two surfaces the arrow touches: the shelf, where the shaft rests, and the vertical face of the window, where it bears. The rectangle goes on the longer surface, the triangle on the shorter: depending on the shape of your window, either one may end up on the shelf. The hairs lie in the direction the arrow leaves. The adhesive does not reposition: take time to aim right.

Fitting the pads

1. **Remove the old pad** if there is one, along with any trace of glue. Clean the window and let it dry: the adhesive does not hold on dust, grease or damp.
2. **Find the contact points** nock an arrow, bow strung, and note where the shaft touches the shelf and the face of the window.
3. **Peel the backing** off one pad without touching the glue with your fingers.
4. **Place each pad** where its shape best covers the contact area you found, hairs lying towards the target, edge level with the arrow's path without intruding on it.
5. **Press firmly** on each pad for a few seconds, working the edges. Let the adhesive set for a few hours before shooting.
6. **Check** by nocking an arrow: it rests flat on the hairs, nothing sticks out into its path, the fletching does not touch the pad.

Specifications

Contents	**2 pads**	Rectangle	**About 5 × 1.6 cm**
Triangle	**About 2.8 × 2.5 cm**	Surface	**Synthetic hair**
Fixing	**Adhesive back**	Colour	**Black**



Soft hairs on an adhesive back: the shaft glides without marking the bow.

GOOD TO KNOW

- A pad lifting at a corner comes off and gets replaced: stuck back on, it will not hold.
- The hairs wear down with shooting; when the shaft touches the backing or the arrow flies off line, change the pad.
- Do not wash the hairs: brush them with a fingertip in their direction, no water or solvent.
- Bow and arrow are shown to illustrate the fitting, they are not supplied.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and compatibility.

© 2026 Sportenzia. All rights reserved.