SPORTENZIA

FITTING GUIDE

HYDROGEL FILM GARMIN FENIX 7S

A thin, soft, discreet hydrogel film that protects the screen of your Garmin Fenix 7S from scratches and light knocks, with an anti-fingerprint coating and touch response preserved. Preparation, fitting, first days.

REF. S20788 · GARMIN FENIX 7S · ULTRA-THIN OLEOPHOBIC HYDROGEL



Before you start

- Work in a room with little dust, hands clean and dry, watch lying flat.
- Clean the screen, then wipe it with a soft lint-free cloth: a speck of dust or a smudge left under the film makes a bubble that will not go away.
- The Fenix 7S screen sits inside a bezel: the film covers the glass surface, without climbing onto the bezel.

Fitting the film

1. **Peel off the liner** that protects the adhesive side of the film, without touching that side with your fingers.
2. **Line up the film** over the screen, centred, with an even gap to the bezel all the way round. Lay it down without pressing: it settles by itself.
3. **Smooth from the centre outwards** with a finger or the cloth to push the air out. The film is soft and follows the curve of the screen.
4. **Push out any remaining bubbles** towards the nearest edge. Tiny bubbles under a hydrogel film usually fade on their own within a few hours.
5. **Remove the top layer** if there is one, lifting it by a corner, then wipe once more.
6. **Let it rest** with the watch flat, not worn and kept dry, while the adhesive sets: overnight is a good guide.

Day to day

- Clean the film with a soft, barely damp cloth. No solvents or abrasive products: they dull the anti-fingerprint coating.
- The film absorbs light impacts and scratches instead of the glass. It does not make the watch unbreakable: a hard knock is still a knock.
- A marked film is replaced: lift it by an edge with a fingernail, clean the screen and fit a new film.

Specifications

Watch	**Fenix 7S**	Material	**Soft hydrogel**
Thickness	**Ultra-thin**	Coating	**Oleophobic**
Protection	**Scratches, knocks**	Touch	**Preserved**

IF SOMETHING GOES WRONG

- A bubble that will not go: there is dust under it. Gently lift the nearest corner, pick the speck off with a piece of sticky tape, lay the film back down.
- An edge lifts: the screen was not clean enough, or the film is touching the bezel. Clean and refit, well centred.
- Touch feels less responsive right after fitting: normal until the air has worked out, sensitivity returns as the film bonds.

DO NOT

- Do not fit the film on a screen that is still damp: let it dry after cleaning.
- Do not reposition a film more than twice: the adhesive loses its grip and picks up dust.
- Do not trim the film: it is cut for the Fenix 7S and does not suit the other Fenix 7 sizes.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and care.

© 2026 Sportenzia. All rights reserved.