SPORTENZIA

QUICK GUIDE

DRAWSTRING MESH BALL BAG

Large mesh bag, 100 cm tall by 76 cm wide, closed with a drawstring and carried on an adjustable shoulder strap. Several footballs or basketballs, training gear, beach or pool kit. Use, adjustment, care.

REF. SACBALLESBLCK · 100 CM × 76 CM, SEVERAL BALLS · MESH, DRAWSTRING, ADJUSTABLE STRAP



What it does

The mesh lets air and water through: wet balls dry inside, sand falls out, and you see at a glance what is missing. The bottom is reinforced with a band of solid fabric, which stands up better to rubbing when the bag is set down or dragged.

Loading and carrying

1. **Loosen the drawstring** by squeezing the cord lock and opening the mouth as wide as it goes.
2. **Load** the heaviest balls first, light items on top. The mesh stretches slightly around the load without losing its shape.
3. **Pull the drawstring tight** and lock it with the cord lock: the opening must be smaller than the smallest ball.
4. **Adjust the strap** at the sliding buckle, bag against the hip or on the back, then carry it across the chest to spread the weight.
5. **Back home** empty the bag, shake out the sand and let it dry open, hung by the strap.

Care

- After the beach or the pool, rinse the mesh in clean water: salt and chlorine weaken the fibres and the cord.
- Hand wash, cold water, mild soap. No machine, no tumble dryer, no bleach.
- Air dry in the shade: direct sun fades and stiffens the mesh.
- Store it dry. A damp bag closed up smells and goes mouldy.

Specifications

Height	**100 cm**	Width	**76 cm**
Closure	**Drawstring**	Carrying	**Adjustable shoulder strap**
Material	**Mesh, solid fabric bottom**	Use	**Balls, gear, beach, swimming**

SAFETY

- A cord is a strangulation hazard: never around a child's neck, never a child inside the bag, even in play.
- Do not overload: if the strap digs into your shoulder or the mesh is stretched to breaking, make two trips.
- With a loaded bag on your shoulder, look behind you before turning round in a changing room or corridor.

GOOD TO KNOW

- The mesh protects from neither rain nor knocks: clothes, electronics and fragile items go elsewhere.
- No pointed or sharp objects (screw-in studs, pegs): they pierce the mesh.
- A hole in the mesh is darned with strong thread before it grows.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about use and care.

© 2026 Sportenzia. All rights reserved.