SPORTENZIA

QUICK GUIDE

MULTI-PURPOSE FISHING BAG

Water-repellent Oxford fabric bag, 37 × 20 × 12 cm, carried across the body, on the shoulder, at the waist or by hand, with rod holders. Fitting the strap, packing, care.

REF. SACPECHMCAMO · 37 × 20 × 12 CM, MAIN COMPARTMENT APPROX. 26 CM · WATER-REPELLENT OXFORD FABRIC, ADJUSTABLE STRAP



In the box

- The bag: main compartment with double zip and two mesh pockets under the lid, zipped front pocket, zipped side pocket, mesh pocket for a bottle, top handle, loops and straps for rods, D-rings on each side.
- An adjustable carry strap with snap hooks.

Setting up

1. **Attach the strap** by its snap hooks to the two D-rings on the bag. Adjust the length at the buckle: across the body, the bag sits on your hip or back; on the shoulder, it stays under your arm.
2. **Or wear it at the waist** with the buckle straps on the back of the bag, tightened so it does not swing as you walk. The top handle is for short carries.
3. **Pack your gear** lure boxes in the main compartment (about 26 cm usable length), small items in the lid mesh pockets, pliers and tools in the side pockets, bottle in the mesh pocket.
4. **Secure the rods** butt in the lower loop, rod flat along the bag, strap tightened around the blank. Up to three rods, reels facing outwards.
5. **Close the zips** all the way before leaving: it is the closed lid that keeps spray off the contents.



Cross-body on the back, rods strapped flat along the side of the bag.

Specifications

Dimensions	**37 × 20 × 12 cm**	Compartment	**Approx. 26 cm usable**
Material	**Water-repellent Oxford**	Carrying	**Cross-body, shoulder, waist, hand**
Rods	**Up to 3**	Closures	**Double zip**
Buckles	**ABS**		

WHAT NOT TO DO

- Do not rely on the bag to protect a phone or papers from driving rain or a dip in the water: the fabric is water-repellent, not waterproof. Keep them in a sealed pouch.
- Do not store loose hooks or rigged lures: always in a box, for your fingers and for the fabric.
- Do not machine wash: brush off dried mud, sponge with warm soapy water, rinse and leave to dry open, in the shade.
- Do not put it away damp or with fish inside: empty, air and dry it after every trip.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about carrying and care.