SPORTENZIA

USER GUIDE

4 L HARD-SHELL FRONT BAG FOR SCOOTER AND BIKE

EVA shell bag with a PU coating that hangs from the handlebar and sits flat against the stem or steering column. 4 L for phone, tools, charger, wallet and keys. Fitting, packing, care and troubleshooting.



REF. SACTROT · SCOOTER AND BIKE, STANDARD HANDLEBAR AND STEM · EVA SHELL, 4 L, ABOUT 230 G

01 · GETTING STARTED

CONTENTS, FITTING, FIRST RIDE

In the box

- The bag, semi-rigid EVA shell with a PU coating, double zip with two sliders.
- Four sewn-on hook-and-loop straps: two at the top for the handlebar, two on the back for the stem or steering column. Inside: a mesh pocket in the lid, another in the body and a key clip.

Where to fit it

In front of a scooter's steering column, or in front of the stem of a city bike, MTB or road bike, below the handlebar. You need a handlebar and stem of standard diameter and, in front of them, room for a bag 30 cm tall: it must touch neither the mudguard, nor the front wheel, nor the brake cables.

Fitting

1. **Hang the bag** from the handlebar: pass each top strap over the bar, one on each side of the stem, fold it back and press firmly.
2. **Press the back** against the stem or column and close the two rear straps around it, pulled tight: the bag must not pivot.
3. **Check the controls:** brake levers, bell, display and cables stay free; on a scooter, the folding mechanism too.
4. **Turn the handlebar fully** both ways: nothing touches the wheel, the mudguard or the frame, and the bag does not swing.
5. **Pack, then close** by bringing the two sliders together at the top of the bag, away from the spray off the wheel.

Specifications

Capacity	**4 L**	Height	**30 cm**
Width	**15.5 cm**	Depth	**13 cm**
Weight	**About 230 g**	Shell	**Semi-rigid EVA**
Coating	**Waterproof PU**	Closure	**Double waterproof zip**
Mounting	**4 hook-and-loop straps**	Inside	**2 mesh pockets, key clip**
Contents	**1 bag**		

ON THE ROAD

- A loaded bag at the front makes the steering heavier, especially on a scooter: take the first corners gently.
- Nothing heavy: the more the bag weighs, the more it pulls on the straps and pivots in corners. No unprotected sharp object against the shell.
- Retighten the straps after the first few kilometres, then before every ride. Never ride with the bag open.

02 · DAY TO DAY

PACKING, CARE, TROUBLESHOOTING

Packing well

- Heaviest items at the bottom, against the back of the bag: charger, tools. Phone in the body mesh pocket, wallet in the lid pocket.
- Keys on the inside clip: they do not fall out when you open the bag in the street.
- Do not overfill: the shell keeps its shape and the zip closes without forcing. If you have to press on the lid, take something out.
- In the rain, the PU coating and waterproof zips protect the contents. To be safe, keep phone and papers in the body pocket, away from the zip.



On a scooter: hung from the handlebar by the top straps, held against the column by the rear straps. Keys on the inside clip.

Care

- Wipe the shell with a damp sponge; stubborn dirt with mild soap. No solvent or alcohol, no machine.
- After rain, open the bag and let it air dry. Do not shut wet items inside.
- Keep the zips clean: a brush over the teeth and the sliders run without forcing.
- Store it away from sunlight and any heat source: the EVA shell deforms with heat.

If something goes wrong

SYMPTOM	LIKELY CAUSE	FIX
Bag pivots in corners	Loose rear straps, load too heavy	Retighten the rear straps, lighten the load
It touches the mudguard or wheel	Hung too low, handlebar too close to the wheel	Move it up the handlebar; if there is no room, this bike is not suited to it
Zip jams	Fabric caught in the teeth, dirty teeth	Back the slider off, free the fabric, brush the teeth
Water inside	Sliders left apart, bag set down in a puddle	Close both sliders end to end; dry with the bag open

GOOD TO KNOW

- Electric scooters (Xiaomi, Segway Ninebot, Dualtron and others), city bikes, MTBs and road bikes: the only requirement is a handlebar and stem of standard diameter, and room in front.
- The bag comes off in seconds: take it with you when you leave the bike or scooter outside, it is not theft-proof.
- The dimensions are those of the shell, straps not included.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and use.