SPORTENZIA

USER GUIDE

FOLDING MAGNETIC FOOTBALL TACTICS BOARD

Zipped folder that opens in two: on the left a magnetic, wipeable pitch with 26 markers, on the right a clipboard for line-ups and instructions. Getting started, using the pens properly, caring for the surface and small fixes.

REF. SPTABCOACH1 · 48 × 33 CM OPEN, 24 × 33 CM CLOSED · 26 MARKERS, 2 PENS, 5 SHEETS



01 · GETTING STARTED

CONTENTS AND FIRST TEAM TALK

In the folder

ITEM	QTY	ROLE
Folding board, magnetic wipeable pitch	1	Player placement, drawings
Magnetic markers	26	Two numbered colours, ball and symbols
Paper tactics sheets	5	Line-ups, notes, instructions
Pens with built-in eraser	2	Drawing on the pitch
Eraser	1	Cleaning the surface
Zipped case	1	Transport, everything stays together

First team talk

1. **Open the zip** around the edge and lay the board flat, or hold it in a V facing the players.
2. **Place the markers** on the green pitch in the formation you want: one colour per team, plus the ball and symbols for the situation.
3. **Draw with a supplied pen** runs, zones, passing lines, straight onto the pitch. Cap the pen after use.
4. **Wipe** with the eraser or the pen's end cap as soon as the situation changes: a line wiped quickly leaves no trace.
5. **Write on a sheet** slipped under the clip on the white side: starters, substitutes, individual instructions. That side is not wipeable, you write on the paper.
6. **Close up** pens in their loop, eraser and markers left on the pitch: the magnets hold, then zip.

Specifications

Open	**48 × 33 cm**	Closed	**24 × 33 cm**
Pitch	**Magnetic, wipeable**	White side	**Clipboard, not wipeable**
Markers	**26**	Closure	**Zip around the edge**

SAFETY

- The markers are small magnets: keep out of reach of young children, a swallowed magnet is a medical emergency.
- Do not leave the pens with unsupervised children: the ink stains fabric.
- Keep the markers away from bank cards and devices sensitive to magnets.

02 · DAY TO DAY

USING IT WELL, CARE, TROUBLESHOOTING

The pitch and the pens

- Write on the pitch only with the supplied pens or dry-erase markers. A permanent marker or a ballpoint damages the surface.
- Wipe after every session: a line left for days is harder to remove.
- Stubborn mark: go over it with the dry-erase pen, then wipe straight away. Failing that, a barely damp soft cloth, never solvent or a scouring pad.
- Cap the pens, ideally tip down: an uncapped pen dries out in a few hours.

The markers and the sheets

- Two numbered colours for the two teams, a ball and symbols (referee, flags): enough for a complete situation.
- The markers stay put when the folder is closed: store them on the pitch rather than loose in the zip.
- The 5 supplied sheets run out: any sheet of paper of the same size slips under the clip.
- To keep a line-up, photograph the board before wiping.

If something goes wrong

SYMPTOM	LIKELY CAUSE	FIX
A line will not come off	Non-erasable pen, or old mark	Go over it with the dry-erase pen and wipe; barely damp cloth
Markers slide	Dirty or greasy surface	Clean the pitch with a soft cloth and let it dry
Pen no longer writes	Left uncapped, ink dried	Replace it with any shop-bought dry-erase marker
Zip catches	Something sticking out, marker between the sides	Pack flat, markers on the pitch, then close without forcing
Sheet slips or falls out	Clip not pressed down, sheet off-centre	Lift the clip, square the sheet against the edge, press the clip fully down



Pen loop, eraser cap, markers, eraser, zip and sheet clip.

GOOD TO KNOW

- The white side is not a whiteboard: you write on the sheets, not on the backing.
- Keep it out of the rain: the case shields from splashes, not a downpour, and a wet sheet is lost.
- Do not leave the folder in a car in the sun: heat and a laminated pitch do not mix.

Place, draw, explain, wipe: a clear team talk fits in one picture.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about use and care.