SPORTENZIA

QUICK GUIDE

MESH BALL BAG WITH CARABINER

Soft mesh net closed by a drawstring, with a carabiner to clip it to a backpack. It takes a basketball, football or volleyball, sizes 4 to 7. Loading, carrying and care on one page.

REF. SPZSACBALBLCK1 · BALLS SIZES 4 TO 7 · SOFT MESH, DRAWSTRING, CARABINER



Before use

The net takes a ball of size 4 to 7: football, basketball, volleyball, training balls. Ball and backpack are not included. Empty, the net folds up and fits in a pocket.

Loading and carrying

1. **Open the net** by pressing the cord lock to slide it up, then spreading the opening with both hands.
2. **Slide the ball in** to the bottom, pull the drawstring and push the cord lock against the mesh: the net should hug the ball, with no play.
3. **Clip the carabiner** to a solid point on the backpack: ring, sewn strap, handle. Never to a zip pull, it would give way.
4. **Carry by hand** from the top loop, or across the body with the cord over your shoulder, ball on your back.
5. **To take the ball out,** press the cord lock, slide it up and spread the opening. Empty, fold the net around the carabiner.



Clipped to a backpack by the carabiner: the ball travels outside, the inside of the bag stays free.

Care

- Hand wash the net in lukewarm water with mild soap; rinse and air dry, hung by the loop. No machine, no tumble dryer.
- A muddy ball dirties the mesh: shake off dry soil before putting the net away in a bag.
- Check the loop seam and the carabiner spring from time to time: it must close on its own.

Specifications

For	**Balls sizes 4 to 7**	Sports	**Basketball, football, volley**
Material	**Soft mesh**	Closure	**Drawstring, cord lock**
Attachment	**Carabiner**	Carrying	**Hand or backpack**
Storage	**Foldable**	Contents	**1 net**

SAFETY

- The carabiner is for carrying a ball: it is not made for climbing, nor for holding a person or a heavy load.
- Keep cord and carabiner out of reach of young children: a cord can wrap around the neck.
- On a bike or scooter, a ball clipped to the bag must neither hang down nor swing: cord pulled tight, carabiner clipped high on the bag.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about compatibility and use.

© 2026 Sportenzia. All rights reserved.