SPORTENZIA

FITTING GUIDE

SILICONE GPS COMPUTER MOUNT

Soft silicone mount for a GPS computer with a standard Garmin interface, held on the handlebar by an adjustable strap, no tools needed. Fitting, removal and troubleshooting.

REF. SUPSILGPSBLK · STANDARD GARMIN INTERFACE · SOFT SILICONE, ADJUSTABLE STRAP



Before fitting

- Check that your computer fits a standard quarter-turn Garmin interface: this is the case for most Garmin, Bryton, IGPS, XOSS, Blackbird and Magene computers.
- Pick a clean, smooth part of the handlebar, close to the stem, clear of brakes and shifters.

Fitting and removal

1. **Place the mount** on the handlebar, platform facing up, where you want it.
2. **Wrap the strap** around the bar and hook one of its holes over the peg. Choose the hole that tensions the strap without forcing it.
3. **Check it holds** by pushing the mount: it must neither turn nor slide. If it does, use the next hole.
4. **Fit the computer** at an angle on the platform, then turn it a quarter turn until it sits straight and locked.
5. **Remove the computer** by turning it a quarter turn the other way, then lift it off. The mount unhooks by hand.

Specifications

Use	**Road, MTB, gravel**	Interface	**Standard Garmin**
Material	**Soft silicone**	Mounting	**Adjustable strap**
Fitting	**Tool-free**	Contents	**Mount, strap**

IF SOMETHING GOES WRONG

- **Mount turns**: strap too loose, use a tighter hole.
- **Computer will not lock**: its interface is not Garmin type.
- **Computer tilts**: centre the mount on top of the bar.

ON THE ROAD

- Check that the mount and computer are secure before every ride.
- Do not handle the computer while riding: stop first.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and compatibility.

© 2026 Sportenzia. All rights reserved.