SPORTENZIA

QUICK GUIDE

PORTABLE 4-DIGIT SCOREBOARD

Manual flip scoreboard: two digits per side, cards mounted on rings, standing like an easel on a table or bench. No battery, no settings: it unfolds, reads from a distance and folds flat. Setting up, scoring, storing.

REF. SZTSCOR4 · 4 DIGITS, TWO SIDES · 36 × 12.5 × 16 CM, FOLDING



How it works

Each position carries a stack of cards numbered 0 to 9, held by two metal rings. Flip one card over the axis to show the next digit. The two left-hand cards count one side, the two right-hand cards the other: tens then units.

Keeping score

1. **Unfold the board** into an easel and set it on a flat, stable surface, facing the players or spectators, outside the playing area.
2. **Reset to zero** all four positions before the match: flip the cards one by one back to 0.
3. **At every point** flip the units card of the side concerned, gently, over the axis.
4. **At ten points** move the tens to the next digit and bring the units back to 0: 09 becomes 10.
5. **After the match** reset to zero, fold flat and store away from damp and knocks.

Courtside

- Suits badminton, table tennis, volleyball, basketball, tennis, tournaments and games: anywhere points are counted by hand.
- Appoint a single scorer per match: with two pairs of hands, the count gets lost.
- The digits read from a distance, but not against the light: turn the board with its back to the sun or the windows.

Specifications

Display	**4 digits, 2 per side**	Type	**Flip cards on rings**
Dimensions	**36 × 12.5 × 16 cm**	Stand	**Easel, flat surface**
Power	**None**	Transport	**Folds flat**

HABITS THAT MAKE IT LAST

- Turn one card at a time, with the fingertips, without pulling: the rings open if forced.
- To go back a point, flip the card the other way rather than going all the way round.
- Fold and unfold without crushing the cards between the two faces.

GOOD TO KNOW

- The cards dislike water: outdoors, bring the board in at the first drop, a warped card no longer turns.
- In strong wind, weight the easel or stand it against a wall: the cards flip on their own.
- A card that has come off its rings goes back on by opening the ring with a fingernail, then closing it.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about use.