USER GUIDE

GARMIN EDGE PACK: CASE AND 2 TEMPERED GLASSES

Black silicone case and two oleophobic 0.5 mm tempered glasses, cut for the Garmin Edge model chosen when ordering. Glass first, case second; the second glass stays dry in reserve.

GARMIN EDGE, CHOSEN MODEL · 2 TEMPERED GLASSES 0.5 MM · BLACK SILICONE CASE



01 · CONTENTS

PACK CONTENTS AND FITTING THE GLASS

In the pack

ITEM	QTY	DETAILS
Silicone case	1	Black, cut for the chosen model; buttons and charging port free
Tempered glasses	2	0.5 mm, oleophobic, touch preserved; the second one as a spare

Fitting the glass

1. **Clean the screen** with alcohol or the damp wipe, dry it with the microfibre, dab it with the tape. Check against the light: no smear, no speck.
2. **Dry-fit the glass** with its film on: it covers the screen without riding onto the frame or getting in the way of the buttons. Note this position.
3. **Peel the film** off the adhesive side, holding the glass by its edges. Do not touch the sticky side again.
4. **Lay one edge** on the mark and let the glass settle: adhesion spreads on its own within seconds.
5. **Push the air out** from the centre to the edges with the microfibre. Any remaining micro-bubbles clear within 24 h.

FITTING ORDER

- **1. The glass**, on a bare, clean screen: this is the step that is hard to redo.
- **2. The case**, whose rim covers the outline of the glass and holds it.
- **3. The computer** clipped onto its mount, case on.

Before fitting

- A room with **no dust in the air** and no draught; clean hands, computer switched off, screen dry.
- Something to clean with: a damp wipe or alcohol, a microfibre cloth, adhesive tape to trap dust.
- Computer **off its mount**: the case slips over the bare unit.

Compatibility

Computer	**The Garmin Edge model chosen when ordering**	Solar versions	**Same housing as the base model**
Glass	**0.5 mm, oleophobic**	Case	**Black silicone**
Kept free	**Buttons, charging, mount**		

02 · FITTING

CASE, CARE, TROUBLESHOOTING

Slipping the case on

1. **Slip the case on** over one end of the computer, then fold it over the other: its rim covers the outline of the glass without lifting it.
2. **Seat every button** in its cut-out; the charging port and the mounting tabs on the back must stay clear.
3. **Clip the computer** onto its mount, case on: it must lock as it does bare, a quarter turn until it clicks.

If something goes wrong

SYMPTOM	LIKELY CAUSE	FIX
White dot with a halo	Dust trapped during fitting	Lift the edge with the tape, pick it off, lay it back down
Stubborn bubble after 24 h	Dust or a greasy smear underneath	Same remedy; clean if the smear comes back
Case lifting an edge of the glass	Glass off-centre	Refit it before slipping the case on
Computer will not lock	Case not seated, or tabs not lined up	Clear the mount cut-out, line up, turn until it clicks



Case and two glasses cut for the same model: the second glass waits in its packaging.

Taking the case off

To clean the computer or change the glass, peel the case off gently from one corner of the housing, never by pulling on a button cut-out: that is where a case tears.

Care

- Case: rinse it in clean water after a muddy ride, dry it before putting it back. No solvent.
- Glass: clean with the microfibre. A glass cracked by an impact has done its job: replace it.
- Keep the second glass dry, in its packaging.

BEFORE YOU RIDE

- Computer locked on its mount: it neither turns nor lifts.
- Buttons responding through the case, charging port accessible.
- Glass with no bubble and no lifted edge.

DON'T

- No glass on a cracked screen, no case slipped on before the glass.
- Do not pull the computer upward to remove it: a quarter turn the other way.

On video

Independent tutorials on fitting glass and a case, scan to watch.

Install tempered glass screen protector (Edge 530)
zulkifli · English

Garmin 830 silicone case and screen protector
Brickfuze · English

Need help?

velkyne.com/contact
Our team answers your questions about fitting, mounting and compatibility.