VELKYNE

USER GUIDE

GARMIN EDGE 1050 PACK: CASE, FILM AND XL MOUNT

Matt black silicone case and a hydrogel film cut for the Garmin Edge 1050, plus an XL out-front mount with a 141 mm arm for the large Edge models. Film first, case second, mount last.



GARMIN EDGE 1050 · HYDROGEL FILM · XL MOUNT, 141 MM

01 · CONTENTS

PACK CONTENTS AND FITTING THE FILM

In the pack

ITEM	QTY	DETAILS
Silicone case	1	Matt black, moulded for the Edge 1050; buttons and charging port free
Hydrogel film	1	Ultra-thin, anti-smudge, touch preserved
XL out-front mount	1	141 mm arm, Garmin quarter-turn plate, bolts supplied

Fitting the film

1. **Clean the screen** with alcohol or the damp wipe, dry it with the microfibre, dab it with the tape. Check against the light: no smear, no speck.
2. **Dry-fit the film** with its liner on: it covers the glass right to its edges and leaves the buttons free. Note this position.
3. **Peel the liner** off the adhesive side by a third only, holding the film by its edges. Do not touch the sticky side.
4. **Anchor the first edge** on the mark, press it down with a soft card, then roll the film onto the screen while removing the rest of the liner.
5. **Smooth from the centre outwards** with the card, press the whole outline, then leave it alone for 24 h: small bubbles clear on their own.

FITTING ORDER

- **1. The film**, on a bare, clean screen: this is the step that is hard to redo.
- **2. The case**, whose rim covers the outline of the film and holds it.
- **3. The mount** on the handlebar, then the computer clipped on with its case.

Before fitting

- A room with **no dust in the air** and no draught; clean hands, computer switched off, screen dry.
- Something to clean with: a damp wipe or alcohol, a microfibre cloth, adhesive tape to trap dust.
- Computer **off its mount**: the case slips over the bare unit.

Compatibility

- **Case and film**: Garmin Edge 1050 only.
- **XL mount**: Edge 1030, 1040, 1050, Explore 1 and 2; its 141 mm arm brings these 117 mm computers out in front of the stem.
- **Pack weight**: about 50 g.

02 · FITTING

CASE, MOUNT, CARE

Slipping the case on

1. **Slip the case on** over one end of the computer, then fold it over the other: its rim covers the outline of the film without lifting it.
2. **Seat every button** in its cut-out; the charging port and the mounting tabs on the back must stay clear.

Fitting the mount

1. **Choose the spot:** on the handlebar, against the stem, arm pointing forward in line with the bike. The long arm places the computer fully in front of the stem. Move cables and hoses aside, nothing should run under the clamp.
2. **Open the clamp,** set it on the bar, then start the supplied bolt without locking it.
3. **Tighten gradually** until the mount no longer turns by hand, without forcing. On a carbon bar, respect the torque given by the bar manufacturer.
4. **Set the screen** level or slightly tilted up, readable without lowering your head, then lock the bolt.
5. **Lock the computer:** tabs in the notches, a quarter turn until it clicks. It should neither turn nor lift.

If something goes wrong

SYMPTOM	LIKELY CAUSE	FIX
White dot with a halo	Dust trapped during fitting	Lift the edge with the tape, pick it off, lay it back down
Edge of the film lifting	Greasy smear underneath	Press with the card; if it lifts again, clean and refit
Case lifting an edge of the film	Film off-centre	Refit it before slipping the case on
Computer will not lock	Case not seated, or tabs not lined up	Clear the mount cut-out, line up, turn until it clicks
Mount rotates on the bar	Bolt not tight enough, or dirty bar	Clean the bar, retighten gradually

Care

- Case: rinse it in clean water after a muddy ride, dry it before putting it back. No solvent.
- Film: clean with the microfibre. A film marked by a deep scratch has done its job: replace it when it gets in the way of reading.
- Mount: check the bolt **after the first ride**, then from time to time; rinse after rain or mud.

DON'T

- No film on a cracked screen, no case slipped on before the film.
- Do not pull the computer upward to remove it: a quarter turn the other way.
- Do not tighten a carbon bar beyond the torque given by its manufacturer, and do not use the mount as a handle.

On video

Independent tutorials: fitting a hydrogel film, mounting a computer. Scan to watch.

How to install a hydrogel screen protector, step by step
Madam C · English

Garmin Edge 540: How to Assemble and Mount on Bike Handlebar
HardReset.Info · English

Need help?

velkyne.com/contact
Our team answers your questions about fitting, mounting and compatibility.