SPORTENZIA

FITTING GUIDE

DUST CAP FOR GARMIN CHARGING PORT

Small soft TPU plug that slips into the charging connector on the back of the watch and keeps it clean and dry between charges: dust, sweat, splashes. Fitting, removal and compatible models on one page.

REF. CMO1 · GARMIN WATCHES, SEE THE LIST · SOFT TPU, CLEAR OR TRANSLUCENT BLACK



Before you start

The cap pushes into the charging port on the back of the case, no tool needed: it holds by friction in the connector. Check that your watch is in the list below: the port changes shape from one generation to the next.

Fitting the cap

1. **Clean the port** with a soft, dry cloth. Nothing must stay trapped under the cap: no moisture, grit or lint.
2. **Line up the cap** solid part towards the connector, tab facing out. If it resists, turn it round rather than forcing it.
3. **Press it in** with a finger until it sits flush with the back of the watch. It must hold without play.
4. **Take it out to charge** by pulling the small side tab with a fingernail: the charger will not connect over it. Refit it once charging is done.

Compatible watches

SERIES	MODELS
Fenix	5, 5S, 5X, 5 Plus, 5S Plus, 5X Plus, 6, 6S, 6X, 6X Baro, 7, 7S, 7X, 7X Solar
Forerunner	45, 45S, 55, 158, 245, 245 Music, 255, 255S, 745, 935, 945, 945 LTE, 955
Venu	Venu, Venu 2, 2S, 2 Plus, Venu Sq
Instinct	Instinct, Instinct 2, 2S, Tide, Tactical
Vivoactive	3, 3 Music, 4, 4S
Vivomove, Vivosmart	Vivomove 3, 3S, Luxe, Style, Sport; Vivosmart 5; Vivosport
Others	Swim 2, Epix 2, Quatix 5, 5 Sapphire, Enduro, Tactix Delta, D2 Charlie, D2 Delta, Approach X10, S60, S62, Move Luxe, Move Style

Specifications

Material	**Soft TPU**	Colour	**Clear or black**
Fitting	**No tool**	Weight	**A few grams**

WHEN TO WEAR IT

Whenever the watch is not charging, and above all at the sea, in the pool, in the rain and during sweaty sessions: that is when the contacts get dirty and corrode.

GOOD TO KNOW

- The cap does not make the watch any more waterproof than it is: it only keeps the contacts clean and dry.
- A cap that floats in the port or will not go in is not made for that watch: do not insist, the contacts are delicate.
- Rinse it in clean water if it gets dirty and dry it completely before refitting.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and compatibility.

© 2026 Sportenzia. All rights reserved.