SPORTENZIA

FITTING GUIDE

TPU PROTECTIVE CASE FOR GARMIN FORERUNNER 965

Soft black TPU case that wraps the edges of the Garmin Forerunner 965. Buttons, screen, sensor and charging stay accessible. Fitting, removal and care on one page.

REF. COQ965 · GARMIN FORERUNNER 965 · SOFT TPU, BLACK



Before you start

The case is cut for the Garmin Forerunner 965 only: each opening matches a button on this model, three on one side, two on the other. Fit it to a clean, dry watch. No tool is needed.

Fitting the case

1. **Clean the watch body** with a soft, dry cloth, right under the lugs: a grain of sand trapped under the TPU scratches over time. If the strap gets in the way, detach it while you fit the case.
2. **Line up the case** openings facing the buttons, three on one side, two on the other. The open back faces the wrist.
3. **Hook one side** over the body, then gently stretch the TPU to bring the other side over. Pull on the solid edge, never on an opening: that is where TPU tears.
4. **Check all the way round** the edge sits flat without ripples or bulges, each button stands proud of its opening and presses freely.
5. **Check the back** heart-rate sensor and charging contacts are clear, the case is open there. Plug in the charger: it clips on without removing the case.

REMOVING THE CASE

Lift the TPU at one lug with a fingernail, then roll the case off towards the other side. It can be refitted as many times as needed.



At the back: heart-rate sensor and charging contacts clear.

Specifications

Compatibility	**Garmin Forerunner 965**	Material	**Soft TPU**
Colour	**Black**	Protection	**Knocks, scratches, dust, splashes**
Screen	**Clear, edges covered**	Charging	**With the case on**
Contents	**1 case**		

GOOD TO KNOW

- The case protects the edges and sides of the body, not the face of the screen: add a screen film or glass for that.
- Ripples, or a button that stays pressed? The case is off-centre, or the watch is not a Forerunner 965. Take it off and start again from the other side.
- Wash the case in warm soapy water and dry it before refitting. No alcohol or solvent: they dull and harden TPU.
- TPU that turns white or has stretched no longer holds: replace it.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and compatibility.