SPORTENZIA

FITTING GUIDE

# CYCLAMI TPU INNER TUBE REPAIR KIT

Eight self-adhesive TPU patches and eight alcohol wipes to repair a small puncture in a TPU inner tube, with no glue. Preparation, fitting and precautions.

**REF. CYCLAMIPATCH8** · TPU INNER TUBES ONLY · 8 PATCHES, 8 WIPES




## Before you start

This kit repairs **TPU** inner tubes **only** (road, mountain or folding bikes), not rubber or butyl tubes. Have a tyre lever and a pump at hand. One patch per repair.

## Fitting the patch

1. **Remove the tyre** with a suitable tyre lever, then take out the inner tube.
2. **Find the leak** by inflating the tube slightly, then locate the hole precisely.
3. **Clean the area** with an alcohol wipe, slightly wider than the patch, then let it dry.
4. **Apply the patch** once its backing is removed, without touching the adhesive side. Centre it over the puncture.
5. **Press firmly** with your fingers, evenly and edges included, for about 1 minute.
6. **Wait** about 30 minutes before refitting the tube. Remove whatever caused the puncture from the tyre.



*Patch applied flat on a TPU inner tube.*

## Specifications

| | | | |
|---|---|---|---|
| Compatibility | **TPU inner tubes** | Patches | **8, TPU, self-adhesive** |
| Size | **About 20 × 31 mm** | Wipes | **8, 75 % ethanol** |
| Finger pressure | **About 1 min** | Waiting time | **About 30 min** |

**SAFETY**

- The wipes contain ethanol: keep them away from flames and heat sources.
- Respect the maximum pressure allowed by your tyre, rim and inner tube.

## Need help?

**sportenzia.com/pages/contact**

Our team answers your questions about the repair.

© 2026 Sportenzia. All rights reserved.