SPORTENZIA

FITTING GUIDE

OXFORD FABRIC CAR BOOT LINER

Waterproof liner that covers the boot floor, rises up the back of the rear seats and the sides, and folds out over the bumper while loading: muddy bike and outdoor gear without soiling or scratching the boot. Fitting, care and precautions on one page.

REF. HOUSSEVOITBLCK · CAR BOOT, FITS WITHOUT TOOLS · WATERPROOF OXFORD FABRIC, HOOK-AND-LOOP AND BUCKLES



Before fitting

The liner is made of a floor, a rear panel that hooks onto the rear seat headrests, two side flaps and a front flap that folds out over the bumper. Hook-and-loop strips and quick-release buckles hold it in place; nothing is screwed or altered on the vehicle.

Fitting the liner

1. **Empty the boot** and vacuum it: a stone trapped under the liner still scratches.
2. **Lay the floor** flat, rear panel against the back of the rear seats, flaps towards the sides.
3. **Hook the rear panel** onto the headrest posts with the straps, clip the buckles and tighten without forcing.
4. **Fix the side flaps** with the hook-and-loop strips so they stand against the boot walls.
5. **Fold the front flap out** over the bumper to load, then fold it back inside before closing the tailgate.

Care

- After each trip, shake the liner out outside then wipe it with a sponge or damp cloth, no products needed.
- Let it dry open, in the air, before folding it: put away damp, it goes mouldy.
- Lay a bike with pedals and derailleur away from the sides: metal pierces, mud does not.



Rear panel against the seats, front flap folded out over the bumper.

Specifications

Material	**Waterproof Oxford fabric**	Fixing	**Hook-and-loop, buckles**
Fitting	**No tools**	Protection	**Mud, water, scratches**
Care	**Wipe clean**	Contents	**1 liner**

LOADING

- The liner holds nothing down: strap the bike and heavy items, braking turns them into projectiles.
- Passengers in the back: the panel must not cover their seat belt buckles or anchors.
- Never trap the flap in the tailgate: folded inside before closing, it does not drag on the road.

GOOD TO KNOW

- Edges and seams are not seals: wipe up a puddle rather than leaving it.
- Rear seats folded: the rear panel lies flat as an extension of the floor.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and care.

© 2026 Sportenzia. All rights reserved.