SPORTENZIA

FITTING GUIDE

TEMPERED GLASS POLAR IGNITE V2

A 9H tempered glass cut for the screen of the Polar Ignite V2, clear and treated against fingerprints. Glass cannot be repositioned like a soft film: everything comes down to lining it up before it touches the screen.

REF. MO1 · POLAR IGNITE V2 · 9H TEMPERED GLASS, OLEOPHOBIC



Before you start

- Work in a room with little dust, hands clean and dry, watch lying flat.
- Clean the screen, then wipe it with a soft lint-free cloth until it is perfectly dry: a speck of dust or a smudge under the glass makes a bubble that will not go away.
- Look at the glass before fitting: its adhesive side is protected by a liner, to be removed at the last moment.

Fitting the glass

1. **Offer up the glass** liner still on, over the screen, to find the centred position: an even gap to the edge all the way round.
2. **Peel off the liner** from the adhesive side, holding the glass by its edges, without touching the sticky side.
3. **Line it up again** holding the glass a few millimetres above the screen. Take your time: once in contact, tempered glass no longer slides.
4. **Lay it down from the centre** and press lightly in the middle: the adhesive spreads to the edges by itself.
5. **Push the air out** smoothing from the centre to the edges with the cloth. Light pressure is enough, glass does not bend.
6. **Check** centring and the absence of bubbles. An off-centre glass is lifted straight away by one edge, with a fingernail, and laid down once more: beyond that, the adhesive no longer holds.

Day to day

- Fingerprints wipe off with a soft cloth; no solvents or abrasive products, which degrade the oleophobic coating.
- The glass takes scratches and rubbing instead of the screen. If it cracks, it has done its job: replace it.

Specifications

Watch	**Polar Ignite V2**	Material	**Tempered glass**
Hardness	**9H**	Clarity	**HD**
Coating	**Oleophobic**	Touch	**Preserved**

IF SOMETHING GOES WRONG

- A bubble that will not go: there is dust under it. Lift the nearest edge with a fingernail, pick the speck off with a piece of sticky tape, lay the glass back down.
- A pale halo around the edge: the glass has not yet bonded over the whole surface. Press from the centre outwards and leave it a few hours.
- The glass is cracked: remove it carefully, lifting one edge with a piece of sticky tape rather than with your fingers.

DO NOT

- Do not fit the glass on a damp or already cracked screen.
- Do not force an off-centre glass by sliding it: lift it and lay it down again.
- Do not wear the watch before the adhesive has set: overnight is a good guide.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting.

© 2026 Sportenzia. All rights reserved.