SPORTENZIA

FITTING GUIDE

SILICONE FINGER SAVERS FOR BOWSTRING

Two soft silicone pieces threaded onto the string, a short one above the nock, a long one below: the fingers pull on silicone, not on the bare string. Fitting, adjustment and precautions on one page.

REF. PRODRED1 · RECURVE AND TRADITIONAL BOWS, LEISURE SHOOTING · SOFT SILICONE, RED, 6 G



Before you start


The set holds a long piece, for the middle and ring fingers below the arrow, a short piece, for the index finger above, and a looped threading wire. The string runs right through each piece, so one string loop must be freed, bow unstrung. Have pliers and a bow stringer ready.

Fitting the finger savers

1. **Unstring the bow** with a bow stringer, never by arm strength or bracing against a foot, and free one string loop from its limb tip.
2. **Hook the wire** its loop into the string loop, then slide the long piece over both legs of the wire and push it up to the string.
3. **Pull with the pliers** on the end of the wire coming out of the piece: the string loop, squeezed, passes through the silicone. Then slide the piece along the string by hand.
4. **Repeat with the short piece** then put the loop back on the limb tip and string the bow with the stringer.
5. **Position the pieces** the short one just above the nocking point, the long one just below, leaving the nock room to clip on without being pinched.
6. **Test at short range** a few arrows on a target: the arrow flies straight, the nock does not rub. If not, move the pieces slightly apart.

Specifications

Material	**Soft silicone**	Colour	**Red**
Weight	**About 6 g**	For	**Recurve, traditional**
Contents	**2 pieces, threading wire**		



The threading wire pulls the string loop through each piece.

STRING UNDER TENSION

- The string of a strung bow stores a lot of energy: always unstring and string with a bow stringer, bow pointed at the ground.
- Never release the string without an arrow nocked: dry firing can break the bow and cause injury.
- The silicone protects the fingers from rubbing; it does not replace string control or the rules of the shooting line.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and use.

© 2026 Sportenzia. All rights reserved.