SPORTENZIA

FITTING GUIDE

GLOVE LEASHES FOR SKIING, SET OF 2

Two elastic nylon wrist leashes, one per wrist, linked by a cord to a clip that hooks onto the glove: take the glove off for your phone or lift pass and it hangs from your wrist instead of dropping. Fitting, adjustment and precautions on one page.



REF. SANGELASTBLCK2 · SKIING, SNOWBOARDING, WINTER SPORTS · ELASTIC NYLON, 25.5 CM UNFOLDED, 2 PIECES

Before you start

Each leash is a wide elastic wrist band with a hook-and-loop closure, a flat cord and a small spring clip. The wrist band is worn over the jacket sleeve or directly on the wrist. The glove needs a loop or a strap at the wrist to clip to: check this before the first day out.

Fitting the leashes

1. **Put on jacket and gloves** as for skiing, then place the wrist band round the wrist, cord on the glove side.
2. **Close the hook-and-loop** so the band stays put without turning or squeezing: two fingers must fit underneath. A tight wrist gets cold fast.
3. **Clip onto the glove** at its loop or strap: open the gate with your thumb, hook the loop, let the gate close. Pull on the glove: it stays clipped.
4. **Do the same** on the other side, with the second leash.
5. **Test** take one glove off: it hangs from the cord within reach, and goes back on without unclipping anything.

ON THE SLOPES

On the chairlift, for a photo or to close a zip, take the glove off and let it hang. Before setting off again, put it back on: a glove flapping about gets in the way of the poles and can catch in the seat.

Specifications

Quantity	2	Material	Elastic nylon
Colour	Black	Unfolded	About 25.5 cm
Fixing	Hook-and-loop, clip		



Clip on the glove strap, band on the wrist: the glove you take off stays hanging.

WHAT NOT TO DO

- The leashes hold a glove, nothing else: never a pole, a phone, a child or yourself to a chairlift bar.
- Do not tighten the wrist loop to the point of restricting circulation; at the first tingling, loosen it.
- A clip that no longer closes or a slack elastic no longer holds the glove: replace the leash.
- Hand wash in warm water, air dry. Rinse the clip after melted snow.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and compatibility.

© 2026 Sportenzia. All rights reserved.