SPORTENZIA

FITTING GUIDE

# BACKPACK STRAPS WITH SWIVEL HOOKS

Pair of padded shoulder straps (Oxford fabric, mesh) joined by a sternum strap, with a swivel hook at each end. They replace the straps of a bag or give straps to a dry bag, a guitar case, a folding chair. Up to 20 kg.



**REF. SANGSACBLCK** · 4 ANCHOR POINTS, UP TO 20 KG · OXFORD FABRIC, MESH, SWIVEL HOOKS

## Before fitting

You need four solid anchor points, two at the top and two at the bottom: D-rings, sewn loops or straps, handles. Without them, the straps cannot be fitted. Each strap has a D-ring for an accessory and a reflective band; the sternum buckle has a whistle. The bag is not included.

## Fitting and adjusting

1. **Clip the top hooks** to the two upper points, padding towards your back, reflective band facing out. Check that each gate has closed.
2. **Clip the bottom hooks** to the two lower points, webbing flat, no twist: the hooks swivel to take up the angle.
3. **Adjust the length** with the lower sliders, bag on your back: it sits flat against your back, weight on the hips rather than the neck.
4. **Close the sternum strap** and adjust it, from 15 to 30 cm, a few centimetres below the collarbones: it holds the straps without restricting breathing.
5. **Test empty, then loaded:** shake the bag, walk a few steps. The hooks stay closed, nothing slips.



*Fitted to a regular bag, or to a dry bag by its four anchor points.*

## Specifications

| | | | |
|---|---|---|---|
| Material | **Oxford, mesh** | Colour | **Black / grey** |
| Max. load | **20 kg** | Length | **46 to 84 cm** |
| Sternum | **15 to 30 cm** | Attachments | **4, swivelling** |
| Clips | **ABS** | Extras | **Reflective, whistle** |
| Contents | **1 pair** | | |

**SAFETY**

- 20 kg at most, anchor points included: a sewn ring that gives way drops the load.
- The hooks are for carrying: never for climbing, a rope or a person.
- Whistle: for signalling in an emergency; explain it to children. The reflective band replaces neither a light nor a vest.

## Care

- Hand wash in lukewarm water with mild soap; dry flat. Rinse the hooks after sand or salt water: the gate must close on its own.
- Before a heavy load, inspect seams, buckles and clips; at the slightest fault, replace the straps.

## Need help?

**sportenzia.com/pages/contact**

Our team answers your questions about fitting and compatibility.

© 2026 Sportenzia. All rights reserved.