SPORTENZIA

USER GUIDE

SHOULDER STRAP FOR CARRYING BIKE AND SCOOTER

Nylon shoulder strap with a non-slip pad, two quick-release buckles and an adjustable length of about 1.5 m. It hooks under the handlebar and under the saddle to carry a bike or a folded scooter on the shoulder, up to 50 kg. Fitting, carrying, safety and care.



REF. SANGVEL1 · BIKE AND SCOOTER, UP TO 50 KG · NYLON, ABOUT 1.5 M, ABOUT 110 G

01 · GETTING STARTED

CONTENTS, FITTING, FIRST CARRY

In the box

- The woven nylon strap, in one piece: a wide non-slip pad that slides along the strap, a sliding adjuster and, at each end, a quick-release buckle that closes a loop.
- Nothing to assemble. The same strap also carries a skateboard, a folding chair or a rolled gym mat.

Where to hook it

Each loop closes around a tube: at the front, under the handlebar (stem or steering column); at the rear, under the saddle (seatpost or seat tube) or near the rear wheel (seat stay, chainstay). Pick two points that do not rotate and will not break: never a cable, a lever, a mudguard or a light.

Fitting and carrying

1. **Open a buckle** by pressing its two tabs, pass the loop around the front tube and close it: the click must be crisp.
2. **Do the same at the rear,** placing the two points either side of the middle of the bike or scooter: hung up, it should stay roughly level.
3. **Adjust the length** at the slider, bike on the ground: standing up, the pad reaches your shoulder without you bending your back.
4. **Lift by bending your knees,** pad in place, one hand on the frame to stop it swinging. Test a few centimetres off the ground before the stairs.
5. **Before riding,** unclip the strap or stow it: a dangling loop can catch in a wheel.

Specifications

Material	**Woven nylon**	Length	**About 1.5 m, adjustable**
Maximum load	**50 kg**	Weight	**About 110 g**
Shoulder pad	**Wide, non-slip**	Buckles	**Quick release**
For	**Bike, scooter, skateboard, folding chair, gym mat**	Contents	**1 strap**

SAFETY

- Maximum load 50 kg: that is the strap's limit, not your back's. A heavy e-bike or scooter is carried by two people, or not at all.
- Carry with a straight back, the weight close to your body, one hand on the frame; on stairs, the other hand on the rail.
- Never tow anything with the strap, never hang the bike from it, never use it to catch a fall: it carries, it does not stop a moving load.
- Keep out of reach of children: a strap with buckles can wrap around the neck.

02 · DAY TO DAY

CARRYING, CARE, TROUBLESHOOTING

Carrying well

- Scooter: fold it first, then hook the front under the handlebar and the rear on the deck, near the rear wheel. Deck against you, it stays level.
- Bike: strap across the body, frame against your hip, one hand on the handlebar so it does not turn. For a few steps, the strap also works as a handle, gripped under the pad.
- A crank that turns or a wheel rubbing your leg: move the rear point forward or back to rebalance.
- On public transport, set the bike or scooter down as soon as you can: the strap stays in place for the next stairs.



Folded scooter carried on the shoulder: one loop under the handlebar, the other at the rear of the deck.

Care

- Hand wash the strap in lukewarm water with mild soap; rinse, dry flat in the air. No machine, no bleach, no tumble dryer.
- Rinse the buckles in clean water if sand or mud gets in: they must click firmly.
- Inspect the strap before every heavy carry: cut, open seam, cracked buckle. At the slightest fault, stop using it.
- Between uses, wind it around the pad and slip it into a bag or pocket.

If something goes wrong

SYMPTOM	LIKELY CAUSE	FIX
Bike tips forward or backward	Attachment points badly spread	Move the lowest point closer to the middle of the bike
Strap slips off the shoulder	Pad badly placed, strap too long	Shorten it, put the pad back on top of the shoulder
A buckle will not lock	Sand in the mechanism, tabs not engaged	Rinse, dry, re-engage until it clicks; if it does not hold, stop using the strap
Loop rotates around the tube	Tapered or very smooth tube	Choose another tube or place the loop against a tube junction

GOOD TO KNOW

- The length of about 1.5 m is that of the strap laid out: once both loops are closed and the length adjusted, the usable shoulder strap is shorter.
- Skateboard, folding chair, gym mat: pass the loops around the object itself, on a solid part, and tighten the adjuster so it does not swing.
- Light and supple, the strap folds into a pocket; the plastic buckles, though, like neither frost nor sun behind glass.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and use.