SPORTENZIA

FITTING GUIDE

GOGGLE STRAP CLIPS FOR SKIING, SET OF 2

Two PP clips with an adhesive back that stick to the helmet shell, one each side, and guide the goggle strap between their two hooks: it no longer rides up or slips down when you get bounced about. Fitting, adjustment and precautions on one page.



REF. SPTZLUFIXBLCK2 · SKIING, SNOWBOARDING, WINTER SPORTS · BLACK PP, ADHESIVE BACK, 2 PIECES

Before you start

Each clip is a small plate with two hooks facing each other, one at the top, one at the bottom: the goggle strap slides underneath and stays trapped between them. The back is adhesive, covered by a film: the clip sticks to the smooth, hard shell of a helmet, once, and cannot be repositioned. No beanie or fabric: the adhesive will not hold.

Fitting the clips

1. **Find the spot** helmet on, goggles in place: the strap runs over each side of the shell, above the ear. That is where each clip goes, centred under the strap.
2. **Clean the shell** there with a clean cloth, then let it dry. The adhesive does not take on dust, grease or a cold surface: fit indoors, not on the slopes.
3. **Stick the clip on** peel the film off the back without touching the glue, line the clip up with its hooks along the strap, and press hard for a few seconds. Let it set for a few hours before the first run.
4. **Fit the second one** on the other side, at the same height, so the strap pulls straight.
5. **Slide the strap** under both hooks: it goes in flat, without a twist, and stays trapped. Shake your head, bend forward: the goggles do not move.

REMOVING A CLIP

Lift one corner with a fingernail and pull slowly; any glue left comes off with a cloth and a little alcohol. A removed clip will not stick again: use a new one.

Specifications

Quantity	2	Material	PP
Colour	Black	Size	4.8 × 3 × 1.2 cm
Fixing	Adhesive back		



The two hooks hold the strap on the side of the helmet.

GOOD TO KNOW

- The clips guide the strap, they do not hold the goggles: tighten the strap as usual.
- In a fall the goggles must be able to come away: do not lock the strap with a knot or tape on top of the clips.
- A clip that comes unstuck or cracks goes in the bin: it will not hold. Stick nothing on a cracked shell.
- Clean with a damp cloth, no solvent on a fitted clip.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about fitting and compatibility.

© 2026 Sportenzia. All rights reserved.