SPORTENZIA

USER GUIDE

WATERPROOF PHONE HOLDER FOR BIKE HANDLEBARS

A zipped pouch with a touch window, clipped onto a handlebar clamp with a ball joint. It shields the phone from rain, mud and dust and stays readable on the move. Mounting, fitting the phone, adjustments and care.

REF. SUP15 · PHONES UP TO 6.3 INCHES · RAIN, MUD, DUST



01 · MOUNTING

CONTENTS, COMPATIBILITY, SETTING UP

In the box

- The waterproof pouch: transparent touch window on the front, zip with two sliders, notched plate on the back.
- The handlebar mount: clamp with thumbscrew, ball joint with locking ring, and a plate that clips onto the back of the pouch.

What it takes

Phones up to **6.3 inches**, standard, mini or lite formats: not the large Max, Plus, Ultra or Pro versions (list on page 2). The clamp tightens on a round handlebar, near the stem.

Setting up

1. **Fit the clamp** on the bar, near the stem, on a round, clean section: open it by unscrewing the thumbscrew, close it around the tube and tighten the thumbscrew by hand, no tools.
2. **Clip the pouch** onto the mount: offer the mount's plate up to the notches on the back of the pouch, press on the base and push forwards until it clicks.
3. **Slide the phone in** screen against the window, zip open. Close the zip all the way and bring the two sliders together: that is where water gets in if it is left ajar.
4. **Aim the screen** by loosening the ball joint ring: portrait or landscape, tilted towards you from the saddle. Tighten the ring firmly.
5. **Shake the assembly** while stationary: neither the clamp on the bar nor the pouch on its plate should move. If they do, tighten the thumbscrew or clip the pouch again.

Specifications

Phones	**Up to 6.3 inches**	Protection	**Rain, mud, dust**
Window	**Touch, transparent**	Closure	**Zip, two sliders**
Mounting	**Handlebar clamp, thumbscrew**	Orientation	**Ball joint, portrait or landscape**

BEFORE RIDING

- Check the hold while stationary by shaking the mount, then the pouch. A click you did not hear is a pouch that jumps off at the first bump.
- The screen works through the window, but only while stopped: on the move, eyes stay on the road, the phone waits.
- A heavy phone tilts the ball joint with vibration: ring tightened well, and a check after the first few kilometres.

02 · DAY TO DAY

COMPATIBLE PHONES, ADJUSTMENTS, CARE

Compatible phones (up to 6.3 inches)

BRAND	MODELS
Apple	iPhone 6, 7, 8, SE (2020 and 2022), X, XS, 11 Pro, 12 mini, 13 mini, 14, 15, 15 Pro; not the Max or Plus
Samsung	Galaxy S10e, S10, S20, S21, S22, S23, S24 (standard models), A52, A53, A54; not the Ultra or Plus
Google	Pixel 4a, 5, 6a, 7a, 8a, Pixel 7; not the Pixel Pro
Xiaomi	Redmi Note 11, 12, 13 (standard), Poco X3, Poco X5; not the Pro or Plus
Huawei, Honor	P30, P40, P50, Honor 50, Honor 70; not the Pro versions
Sony	Xperia 10 III, IV, V, Xperia 5 series
Others	Most Lite, Mini or standard models of 6.3 inches or less

Adjustments, removal, care

- To take the phone back, open the zip: the pouch stays clipped on. To remove the pouch, press the base of the mount and pull it backwards.
- After rain, take the phone out and let the pouch dry open: closed while damp, it fogs the window.
- Clean the window with a soft damp cloth, never dry when it is sandy.
- In the sun, when parked, take the phone out: inside the closed pouch it heats up fast.
- Check the clamp thumbscrew and the ball joint ring from time to time: vibration loosens them.

If something goes wrong

SYMPTOM	LIKELY CAUSE	FIX
Screen does not react through the window	Drops, window lifted off the screen, gloves	Wipe, press the phone against the window
Pouch does not click	Plate outside the notches	Line it up again, push forwards
Pouch tilts while riding	Ball joint ring loose	Tighten it firmly



The pouch and its handlebar mount: thumbscrew clamp, ball joint, clip-on plate.

GOOD TO KNOW

- Waterproof against rain, mud and splashes, not immersion: do not dip the pouch in water or hose it down.
- The window passes touch, not always a fingerprint: unlock with a code or your face.
- A phone over 6.3 inches strains the zip and ends up opening it: respect the size.

Need help?

sportenzia.com/pages/contact

Our team answers your questions about mounting and compatibility.