USER GUIDE

GARMIN EDGE 850 / 550 PACK: GLASS, CASE AND MOUNT

9H tempered glass with a 2.5D finish, soft silicone case and aluminium handlebar mount with clamp bolt, for the Garmin Edge 850 and 550. Cleaning wipes included. Glass first, case second, mount last.

GARMIN EDGE 850 / 550 · TEMPERED GLASS 9H, 2.5D · ALUMINIUM MOUNT



01 · CONTENTS

PACK CONTENTS AND FITTING THE GLASS

In the pack

ITEM	QTY	DETAILS
Silicone case	1	Soft, black, for Edge 850 / 550; buttons and ports accessible
Tempered glass	1	9H, 2.5D finish, clear, touch preserved
Handlebar mount	1	Aluminium alloy, black, rotating system, clamp bolt supplied
Wipes	2	One wet, one dry

Fitting the glass

1. **Clean the screen** with the wet wipe, then the dry one, and dab it with the tape. Check against the light: no smear, no speck.
2. **Dry-fit the glass** with its film on: it covers the screen without riding onto the frame or getting in the way of the buttons. Note this position.
3. **Peel the film** off the adhesive side, holding the glass by its edges. Do not touch the sticky side again.
4. **Lay one edge** on the mark and let the glass settle: adhesion spreads on its own within seconds.
5. **Push the air out** from the centre to the edges with the microfibre. Any remaining micro-bubbles clear within 24 h.

FITTING ORDER

- **1. The glass**, on a bare, clean screen: this is the step that is hard to redo.
- **2. The case**, whose rim covers the outline of the glass and holds it.
- **3. The mount** on the handlebar, then the computer clipped on with its case.

Before fitting

- A room with **no dust in the air** and no draught; clean hands, computer switched off, screen dry.
- The two supplied wipes (wet, then dry), a microfibre cloth and a piece of adhesive tape to trap dust.
- Computer **off its mount**: the case slips over the bare unit.

Compatibility

Computer	**Edge 850, Edge 550**	Glass	**Tempered 9H, 2.5D**
Case	**Soft silicone, black**	Mount	**Aluminium, black**
Protects from	**Impacts, scratches, drops, dust, water**		

02 · FITTING

CASE, MOUNT, CARE

Slipping the case on

1. **Slip the case on** over one end of the computer, then fold it over the other: its rim covers the outline of the glass without lifting it.
2. **Seat every button** in its cut-out; the charging port and the mounting tabs on the back must stay clear.

Fitting the mount

1. **Choose the spot:** on the handlebar, against the stem, arm pointing forward in line with the bike. Move cables and hoses aside, nothing should run under the clamp.
2. **Open the clamp,** set it on the bar, then start the supplied bolt without locking it.
3. **Tighten gradually** until the mount no longer turns by hand, without forcing. On a carbon bar, respect the torque given by the bar manufacturer.
4. **Set the screen** with the rotating system: level or slightly tilted up, readable without lowering your head, then lock the clamp bolt.
5. **Lock the computer:** tabs in the notches, a quarter turn until it clicks. It should neither turn nor lift.

If something goes wrong

SYMPTOM	LIKELY CAUSE	FIX
White dot with a halo	Dust trapped during fitting	Lift the edge with the tape, pick it off, lay it back down
Stubborn bubble after 24 h	Dust or a greasy smear underneath	Same remedy; clean if the smear comes back
Case lifting an edge of the glass	Glass off-centre	Refit it before slipping the case on
Computer will not lock	Case not seated, or tabs not lined up	Clear the mount cut-out, line up, turn until it clicks
Mount rotates on the bar	Bolt not tight enough, or dirty bar	Clean the bar, retighten gradually

Care

- Case: rinse it in clean water after a muddy ride, dry it before putting it back. No solvent.
- Glass: clean with the microfibre. A glass cracked by an impact has done its job: replace it.
- Mount: check the bolt **after the first ride**, then from time to time; rinse after rain or mud.

DON'T

- No glass on a cracked screen, no case slipped on before the glass.
- Do not pull the computer upward to remove it: a quarter turn the other way.
- Do not tighten a carbon bar beyond the torque given by its manufacturer, and do not use the mount as a handle.

On video

Independent tutorials: fitting tempered glass, mounting a computer. Scan to watch.

Install tempered glass screen protector (Edge 530)
zulkifli · English

Garmin Edge 540: How to Assemble and Mount on Bike Handlebar
HardReset.Info · English

Need help?

velkyne.com/contact
Our team answers your questions about fitting, mounting and compatibility.

 © 2026 Velkyne. All rights reserved.