VELKYNE

USER GUIDE

GARMIN EDGE EXPLORE 2 PACK: 2 GLASSES, CASE AND XL MOUNT

Black silicone case, two tempered glasses cut for the Garmin Edge Explore 2 and an XL out-front mount with a 141 mm arm for large Garmin computers. Glass first, case second, mount last.

GARMIN EDGE EXPLORE 2 · 2 TEMPERED GLASSES · XL MOUNT 141 MM



01 · CONTENTS

PACK CONTENTS AND FITTING THE GLASS

In the pack

ITEM	QTY	DETAILS
Silicone case	1	Black, ultra-light; buttons and charging port free
Tempered glass	2	High clarity, smudge-resistant; the second is a spare
XL out-front mount	1	141 mm arm, forward position, bolt included

Fitting the glass

1. **Clean the screen** with alcohol or a damp wipe, dry it with the microfibre, dab it with the tape. Check against the light: no smear, no speck.
2. **Dry-fit the glass** with its film on: it covers the screen without riding onto the frame or blocking the buttons. Note this position.
3. **Peel the film** off the adhesive side, holding the glass by its edges. Do not touch the sticky side again.
4. **Set one edge down** on the mark and let the glass settle: adhesion spreads on its own within seconds.
5. **Push out the air** from the centre to the edges with the microfibre. Small remaining bubbles clear within 24 h.

FITTING ORDER

- **1. The glass**, on a bare, clean screen: this is the step that is hard to redo.
- **2. The case**, whose edges cover the outline of the glass and hold it down.
- **3. The mount** on the handlebar, then the computer clipped on with the case in place.

Before you start

- A room with **no dust in the air** and no draught; clean hands, computer switched off, dry screen.
- Cleaning kit: damp wipe or alcohol, microfibre cloth, adhesive tape to trap dust.
- Computer **off its mount**: the case slips onto the bare device.

Compatibility

Case, glasses	**Edge Explore 2**	XL mount	**1030, 1040, 1050, Explore 1 and 2**
Arm	**141 mm**	Computers	**114 to 117 mm**
Protects from	**Impacts, scratches**	Bolt	**Included**

02 · FITTING

THE CASE, THE MOUNT, CARE

Fitting the case

1. **Slip the case on** from one end of the computer, then fold it over the other: its edges cover the outline of the glass without lifting it.
2. **Seat each button** in its cut-out, and check that the charging port and the quarter-turn mount on the back stay fully clear.
3. **Wait for the mount** before clipping the computer on: it locks with the case in place, just as it does bare.

Fitting the XL mount

1. **Choose the spot:** on the handlebar, against the stem, arm pointing forward in line with the bike: the 141 mm arm puts the whole computer in front of the stem. Move cables and hoses aside, nothing should run under the clamp.
2. **Open the clamp,** set it on the bar, then start the supplied bolt without locking it.
3. **Tighten gradually** until the mount no longer turns by hand, without forcing. On a carbon bar, respect the torque given by the bar manufacturer.
4. **Set the screen** level or slightly tilted up, readable without lowering your head, then lock the bolt.
5. **Lock the computer:** tabs in the notches, a quarter turn until it clicks. It should neither turn nor lift.

Care

- The case: wash it in warm soapy water, dry before putting it back; after rain, take it off so the water trapped between case and body can dry. No solvent.
- The glass: clean it with the microfibre. Cracked after an impact, it has done its job: replace it with the second one, kept flat in its packaging.
- The mount: check the bolt **after the first ride**, then from time to time; rinse after rain or mud.

If something goes wrong

SYMPTOM	LIKELY CAUSE	FIX
White dot under the glass	Trapped dust	Lift the edge, remove it, lay it back
Stubborn bubble after 24 h	Dust or greasy smear	Same fix
Case lifts one edge of the glass	Glass off-centre	Refit it before the case
Mount rotates on the bar	Bolt not tight enough, dirty bar	Clean the bar, retighten

DON'T

- No glass on a cracked screen, no case put on before the glass.
- Do not pull the computer upward to remove it: a quarter turn the other way.
- Carbon bar: never beyond the torque given by its manufacturer. The mount is not a handle.

On video

Scan to watch.

Install tempered glass screen protector (Edge 530)
zulkifli · English

Garmin Edge 540: How to Assemble and Mount on Bike Handlebar
HardReset.Info · English

Need help?

velkyne.com/contact
Our team answers your questions about fitting and mounting.