FITTING GUIDE

BATTERY COVER FOR SRAM AXS DERAILLEURS

Vented PVC shell, 9 g, clipped around the battery of SRAM Eagle AXS GX, X01 and XX1 derailleurs: it takes the hits, spray and branches in its place, and comes off in one move for charging.



SRAM EAGLE AXS GX, X01, XX1 · HIGH-STRENGTH PVC, VENTED · ≈ 9 G, NO TOOLS

What it does

The battery sits at the back of the derailleur, at rock and branch height; damaged, the bike stops shifting. The cover surrounds it, its holes let air through and shed mud.

Fitting, step by step

1. **Check the derailleur:** Eagle AXS GX, X01 or XX1, battery in place, latch closed, surroundings clean.
2. **Offer up the cover** around the battery, vented face outwards: it should hug it with no play.
3. **Clip it on without forcing** onto the derailleur body. If it resists, it is upside down.
4. **Run through every gear at a standstill** turning the cranks: nothing must touch the cassette or the spokes.
5. **To charge,** unclip it, remove the battery as usual, put it back before riding off.

Care

- Rinse with a gentle hose along with the bike; unclip it now and then to clean underneath.

Specifications

Derailleurs	**Eagle AXS GX, X01, XX1**	Material	**PVC**
Weight	**≈ 9 g**	Fixing	**Clip-on, no tools**

IF SOMETHING GOES WRONG

- **It will not clip on**: wrong way round, or a derailleur not on the list; never force it.
- **It moves or rattles**: refit until it clicks on both sides.
- **It rubs in one gear**: check it is seated flat; otherwise remove it and contact us.

DON'T

- No fitting on a road AXS derailleur or a T-Type transmission: different battery. No charging with the cover on. It protects the battery, not the derailleur.

On video

Independent tutorial, scan to watch.

Remove and install a battery protector on an Eagle AXS derailleur

Pascal RIDE · English

Need help?

velkyne.com/contact

Our team answers your questions about fitting and compatibility.

© 2026 Velkyne. All rights reserved.